

Valid for Software Levels B.2x and up
EPROM Part No. D699B181U01/U02



Product Designation
FXF2000 (COPA-XF)

Operating Instruction

Part No. D184B084U02

Issued date: 12.05

Revision: 01

Manufacturer:

ABB Automation Products GmbH
Dransfelder Str. 2
37079 Göttingen, Germany

Telephone: +49 (0) 55 19 05- 0

Telefax: +49 (0) 55 19 05- 777

© Copyright 2005 by ABB Automation Products GmbH
We reserve the right to technical amendments.

This document is protected by copyright. Information in this document is intended only to assist the user in the safe and effective operation of the equipment. Its contents are not to be reproduced in full or in part without prior written approval from the copyright owner.

1	Safety Information	5
1.1	Basic Safety Requirements	5
1.1.1	Instrument Safety Standards	5
1.1.2	Regulated Usage	5
1.1.3	Specification Limits	5
1.1.4	Allowable Fluids	6
1.1.5	Safety Marks, Symbols, Type and Factory Tags and CE-Mark	6
1.1.6	Type Plate / Factory Plate / EHEDG Label	7
1.1.6.1	Type Plate Specifications	7
1.1.6.2	Factory Plate Specifications	7
1.1.6.3	Specifications on the EHEDG Label	8
1.1.7	Qualification of the Personnel	8
1.1.8	Responsibilities of the Operator	8
1.1.9	Possible Dangers When Transporting the Instruments	8
1.1.10	Possible Dangers During Installation	8
1.1.11	Possible Dangers During Electrical Installation	8
1.1.12	Possible Dangers During Normal Operation	9
1.1.13	Possible Dangers During Inspection and Maintenance	9
1.1.14	Returns	9
1.2	Overview of the Flowmeter Primary and Converter Designs Overview Process Connections ..	10
2	Accuracy, Reference Conditions and Operating Principle	11
2.1	Description	11
2.2	Operating Principle	11
2.3	Design	11
2.4	Reference Conditions per EN 29104	11
3	Assembly and Installation	13
3.1	Inspection	13
3.2	Transport General	13
3.2.1	Shipment Contents	13
3.2.2	Shipped Status	13
3.3	Installation Requirements, Flowmeter Primary	13
3.3.1	Installation	13
3.3.2	Recommended Installation Conditions	14
3.3.3	In- and Outlet Sections	14
3.3.4	Tightening Torques	15
3.3.4.1	Tightening Torque MA for Series 2000 „Multi-Connection“ Based on the PED(DGRL) Calculations using EPDM Gaskets	15
3.3.4.2	Tightening Torques MA for Series 2000 with PFA Liners „Wafer Design“ Based on the PED(DGRL) Calculations	15
3.3.5	3A Conformity	15
3.4	Protection Class Relative to EMC	16
3.5	Flowrate/Pressure Drop Tables and Nomograph	17
3.5.1	Meter Size and Pressure Rating (Weld Stubs) with Flow Ranges	17
3.5.2	Effective Flow Velocities, Variable Process Connections, PFA	17
3.5.3	Flowrate Nomograph	18
3.5.4	Pressure Drop Calculations	19
4	Grounding, Electrical Connections	20
4.1	General	20
4.2	Grounding the Flowmeter Primary	20
4.3	Interconnection Diagram for the FXF2000, P-Switched, Design Level B, Plug Assignments....	20
4.4	Interconnection Examples for Peripherals FXF2000 (COPA-XF), Model DF23, P-Switched In-/Outputs / Data Link	22
4.5	Communication	23

4.5.1	TTL-Service-Data Link for CommuniCation with Operator Unit 55BE1000 or the Configuration Software	23
4.5.2	RS485 Data Link for Communication with the Handheld Terminal 55HT4000 or a Higher Level Communication Unit	24
5	Start-Up and Maintenance of the Flowmeter	25
5.1	Sockets for the Memory Module (external EEPROM) and the Operator Unit	25
5.2	Exchanging Components	25
5.2.1	Exchanging a Flowmeter Primary	26
5.2.2	Exchanging a Converter	26
5.3	System Zero Check	26
5.4	Detector Empty Pipe	26
5.5	Storing the Parameter Settings	26
5.6	Data Storage	26
5.7	Maintenance/Repair	27
6	Specifications Flowmeter Primary DF23	28
6.1	Min. Allowable Absolute Pressure as a Function of the Fluid Temperature	28
6.2	Maximum Allowable Fluid Temperature and Pressure	28
6.3	Maximum Allowable Cleaning Temperature PFA-Design	28
6.4	Maximum Allowable Shock Temperature	28
6.5	Ambient Conditions	28
6.6	Classifications per Pressure Equipment Directive (PED/DGRL)	29
6.7	Variant Overview Series 2000 (Stainless Steel Design) Model DF23	29
6.8	Material Load Curve for Wafer Design Instruments Model DF23	29
6.9	Materials Flowmeter Primary	30
6.10	Process Connection Material	30
6.11	Gasket Material, Electrical Connections, Weight and Design	30
6.12	Certifications /Approvals	31
6.13	Dimension Drawings DF23	32
6.13.1	Dimension Drawings, Flowmeter Primary DN 3-100 [1/10"-4"], Wafer Design, PFA	32
6.13.2	Dimension Drawings, flowmeter primary DN 3-100, Variable Process Connections, PFA, Series 2000	33
6.13.3	Dimension Drawings, Adapters for Variable Process Connections, Series 2000	34
7	Specifications Converter F4	36
7.1	Specifications Converter FXF2000 (COPA-XF)	36
7.2	Overview, Possible Converter Variants with Their Hardware Options and Operating Modes....	37
7.3	Functional Schematic of the FXF2000 (COPA-XF) as „Flow Sensor“ or „Stand-Alone Filler“ ...	38
8	Ordering Numbers, Electromagnetic Flowmeter Model DF23	39
9	Error Messages and Testing	41
9.1	Error Messages During Operation	41
9.2	Error Messages During Data Entry	42
10	Parameter Setting Overview with Default Values	43
10.1	Specification Help: FXF2000, 50XF4000, Design-Level B, Variant 02	43
10.2	Specification Help: FXF2000, 50XF4000, Design-Level B, Variant 07	44
11	Data Entry and Programming Using Operator Unit 55BE1000	45
11.1	Data Entry and Programming Using Operator Unit 55BE1000	45
11.2	Parameter Overview	46
12	Certificates	62
12.1	EC-Declaration of Conformity (DGRL 97/23/EG)	62
12.2	EC-Certificate of Compliance (EMC Directive)	63

1 Safety Information

1.1 Basic Safety Requirements

1.1.1 Instrument Safety Standards

- This instrument complies with the safety requirements of the Pressure Equipment Directive and uses state of the art technology in its design. It was tested and shipped from our factory in a safe operating condition. In order to maintain this condition during operation, the requirements listed in this Operation Manual must be observed and followed.
- The instrument satisfies the EMC-Requirements in EN61326 / NAMUR NE21.
- When a power interruption occurs, all instrument parameters are stored in a NVRAM. After the power is restored, the instrument is ready for operation immediately.

1.1.2 Regulated Usage

This instrument is to be used for

transporting the flow of electrically conductive liquids, slurries or sludges and metering:

- the volumetric flow or
- the mass flow (at constant pressure/temperature) when mass engineering units have been selected
- continuous flows or batch processes (dependent on selected Operating Mode)

The regulated usages include:

- installation within the specification technical limits
- observing and following the information relating to the allowable fluids.
- observing and following the information in this Operation Manual
- observing and following the information in the accompanying documentation (Specifications, Diagrams, Dimensions)

The following usages of the instrument are not permissible:

- operation as an elastic compensation member in the pipeline, e.g. to compensate for pipe misalignment, pipeline vibrations, pipeline expansions, etc.,
- use as a climbing support, e.g. for assembly purposes,
- use as a support for external loads, e.g. support for the pipeline, etc.
- material addition by painting over the type plate or adding parts by welding or soldering
- material removal, e.g., by drilling into the housing
- repairs, modifications and expansions and the use of replacement parts is only permissible as described in the Operation Manual. Extensive operations must be approved by us. Excepted are repairs made in locations authorized by ABB. For unauthorized activities we accept no liability.

The operation and maintenance requirements in this Operation Manual must be observed. For damage resulting from improper or non-regulated usage the manufacturer assumes no liability.

1.1.3 Specification Limits

The instrument is to be used exclusively within the limits specified on the type plate and listed in the Operation Manual. The following limits are to be observed:

- The allowable pressure (PS) and the allowable fluid temperature (TS) may not exceed the pressure/temperature values (p/T-ratings) listed in this Operation Manual.
- The maximum operating temperature listed in the instrument Specifications may not be exceeded.
- The allowable ambient temperature listed in the instrument Specifications may not be exceeded.
- The Protection Class is IP 67 per EN60529
- Only original equipment instrument gaskets may be used.
- Graphite may not be used for the gaskets because, under certain conditions, it may be possible that an electrically conductive coating may form on the interior of the meter pipe





- The flowmeter may not be installed near strong electromagnetic fields, e.g. motors, pumps, transformers, etc.. A minimum distance of 100 mm should be maintained. For installations on or to steel parts (e.g. steel supports) a minimum distance of approx. 100 mm should be maintained. (Values were determined based on IEC801-2 or IEC TC 77B (SEC 101)).

1.1.4 Allowable Fluids

- Only such fluids may be metered for which assurance is available, either based on available technology or past experience by the user, that the required chemical and physical resistance of the materials of the fluid wetted parts (electrodes, grounding electrodes, liner, process connections, grounding plates or protection plates) will not be adversely affected during the operating life of the instrument.
- Fluids with unknown characteristics or which are abrasive may only be metered if the user institutes a regular and appropriate inspection program to assure the safe condition of the instrument.
- The specifications on the type plate are to be observed.

1.1.5 Safety Marks, Symbols, Type and Factory Tags and CE-Mark

All safety marks, symbols and the type plates should be maintained in a readable state and protected from damage or loss. Note the following generalized information:

	Warning!	Information indicating that a risk or danger exists which could result in serious or fatal injuries to personnel.
	Attention!	Information indicating a possible dangerous situation. If not corrected, the product or something in its vicinity may be damaged.
	Information!	The „Information“ symbol is a user tip or other particularly important information, which if ignored could result in loss of operating ease or affect the instrument functionality.
	CE-Mark!	<p>The CE-Mark identifies compliance of the instrument with the following directives and satisfying the basic safety directives:</p> <ul style="list-style-type: none"> • CE-Mark on the type plate (on the converter) <ul style="list-style-type: none"> – Compliance with the EMC-Directive 89/336/EEG • CE-Mark on the factory plate (on the flowmeter primary) <ul style="list-style-type: none"> – Compliance with the Pressure Equipment Directive (DGRL) 97/23/EEG <p>Pressure equipment will not have a CE-Mark on the factory plate if:</p> <ul style="list-style-type: none"> – the max. allow. pressure (PS) is less than 0.5 bar. – there are minimal pressure risks (meter sizes ≤ DN 25 [1"]) therefore a compliance evaluation is not required. – the instruments are used as water meters in Water/Waste Water facilities. <p>Applies to sizes >DN 600 [24"].</p>

1.1.6 Type Plate / Factory Plate / EHEDG Label


1.1.6.1 Type Plate Specifications

The type plate is located on the converter housing.



Note:

Information regarding the instrument design, parameter settings and the original calibration data may be obtained from the factory whenever required using the Order No.




The identification of the converter design may be found on the plate on the metal frame of the converter module or on the type plate on the converter housing.

Variant 02	Contact output + Pulse passive, Opto + Contact input + RS485 (2nd plug)
Variant 07	Contact output + Pulse passive, Opto + Contact input + Current output (standard)
Variant ≥ 20	User specified converter design


1.1.6.2 Factory Plate Specifications

The factory plate is located on the flowmeter primary housing. There are two different factory tags dependent on whether the instrument falls into the applicability range of the PED, (see also Sect. 3 Par. 3 PED/DGRL 97/23/EC):

a) Pressure Equipment within the Applicability Range of PED/DGRL




b) Pressure Equipment not within the Applicability Range of PED/DGRL

	<p>The factory plate includes essentially the same specifications as the one described in a) above with the following differences:</p> <ul style="list-style-type: none"> • There is no CE-Mark for the pressure equipment per Sect. 3 Par. 3 of the PED/DGRL because the pressure equipment is not within the applicability range of the Pressure Equipment Directive 97/23/EC. • In the PED, the basis for the exception is given in Sect. 3 Par. 3 of the PED/DGRL. The pressure equipment is categorized under the section SEP (=Sound Engineering Practice).
---	---

1.1.6.3 Specifications on the EHEDG Label

The EHEDG-Logo on the instrument certifies that the instrument complies with the complete scope of the EHEDG-Test criteria for use in hygienic applications.

	<ul style="list-style-type: none"> • Logo with Certifying Location • Type of certification • Date of the certification
---	---

1.1.7 Qualification of the Personnel

- The electrical installation, start-up and maintenance of the instrument should only be carried out by trained personnel authorized by the system operator. The personnel must read and understand the Operation Manual and follow its instructions.

1.1.8 Responsibilities of the Operator

- Before metering corrosive or abrasive fluids the operator must evaluate the resistance of the fluid wetted parts. ABB will gladly provide assistance in their selection, but cannot assume any liability.
- Observe the national standards in your country applicable to testing, operation, repair and maintenance of electrical instruments.

1.1.9 Possible Dangers When Transporting the Instruments

Note when transporting the instrument to the installation site:

- that the center of gravity may be off-center.
- the protection plates or caps mounted on the process connections for PTFE/PFA lined meters should only be removed just prior to installing the instrument in the pipeline.

1.1.10 Possible Dangers During Installation

Before installing assure that:

- the flow direction corresponds with the arrow on the instrument, if present.
- the instrument is installed in a stress free manner (torsion, bending), fixed clamps / multiconnections are installed with axisymmetric, parallel mating fittings and the gaskets used are suitable for the anticipated operating conditions.

1.1.11 Possible Dangers During Electrical Installation

The electrical connections may only be made by authorized and trained personnel in accordance with the Interconnection Diagrams.

- In particular observe the information regarding the electrical connections in this Operation Manual, otherwise the electrical protection type may be adversely affected.
- Ground the flowmeter system.



Attention!

When the housing cover is removed, EMC and personnel protection are no longer provided.

- Before opening the housing cover, the supply power should be turned off.
- Installation and maintenance tasks may only be performed by trained personnel.

1.1.12 Possible Dangers During Normal Operation

- When metering hot fluids, touching the flowmeter primary surface could cause burns.
- Aggressive or corrosive fluids could cause damage to the liner or electrodes resulting in unexpected leakage of fluid under pressure.
- Due to fatigue of the process connection gaskets (e.g. Food Industry fittings, Tri-Clamp etc.) leaks of the fluid under pressure could occur.
- The internal flat gaskets for the process connections „Multiconnection“ can become brittle due to the CIP/SIP process.

1.1.13 Possible Dangers During Inspection and Maintenance

- Before removing the instrument assure that the instrument and adjacent piping or tanks have been depressurized.
- Before opening the instrument, check if the instrument was used to meter dangerous fluids. It may be possible that hazardous residues may still be present in the instrument which could exit when the meter is opened.
- Within the framework of operator responsibilities, perform a regular inspection of the instrument including:
 - the pressure containing walls/liners of the pressure equipment
 - proper metering function
 - seal integrity
 - wear (corrosion)



Warning!

- Exercise care if an instrument should fail before removing the cover because dangerous fluid could leak from the instrument. Assure that the pipeline is depressurized before opening the instrument.

1.1.14 Returns

- If it is necessary to return the instrument for repair or recalibration to the ABB factory in Göttingen, Germany, use the original packaging material or a suitably protective packing material. Please indicate the reason for the return.




Important! EC Hazardous Material Directives

The owner of special wastes is responsible for its decontamination and must satisfy the following requirements before shipping the materials:

- All flowmeter primaries and/or flowmeter converters which are returned to ABB for repair are to be free of any hazardous materials (acids, bases, solvents, etc.). This includes flushing and decontaminating the hazardous materials which may be present in the cavities in the primaries between the meter pipe and the housing. For flowmeter primary sizes \geq DN 350 [14"] the inspection screw (for blowing out condensate) in the lower section of the housing is to be removed so that and hazardous materials may be decontaminated or to flush the area of the coils and electrodes to neutralize it. Written confirmation that these measures have been carried out should accompany the flowmeter.
- If the user cannot completely remove the hazardous materials, then appropriate documents should accompany the shipment acknowledging this condition. Any costs incurred by ABB to remove and decontaminate the hazardous materials during the repair will be billed to the owner of the instrument.

**1.2 Overview of the Flowmeter Primary and Converter Designs
Overview Process Connections**



Flowmeter Primary Specifications

Accuracy Specifications

Measurement deviations	0.5 % of rate	0.5 % of rate
Reproducibility	0.2 % of rate	0.2 % of rate

Flowmeter Primary

Process Connections	Meter size				Meter size			
	DN	Inch	Max. pres. PN	Material	DN	Inch	Max. pres. PN	Material
Wafer Design	DN3-100 1/10" – 4"	DN 3 – 50 1/10" – 2"	10 – 40	W	–	–	–	–
		DN 65 – 100 2½" – 4"	10 – 40	W				
Weld stubs DIN 11850	–	–	–	–	3 – 40	1/10" – 1½"	40	R
					50, 80	2", 3"	16	R
					65, 100	2½", 4"	10	R
Weld stubs DIN 2463	–	–	–	–	3 – 40	1/10" – 1½"	40	Q
					50, 80	2", 3"	16	Q
					65, 100	2½", 4"	10	Q
Weld stubs ISO 2037	–	–	–	–	25 – 40	1" – 1½"	40	P
					50, 80	2", 3"	16	P
					65, 100	2½", 4"	10	P
Weld stubs SMS	–	–	–	–	25, 40	1" – 1½"	40	X
					50, 80	2", 3"	16	X
					65, 100	2½", 4"	10	X
Pipe couplings DIN 11851	–	–	–	–	3 – 40	1/10" – 1½"	40	S
					50, 80	2", 3"	16	S
					65, 100	2½", 4"	10	S
Tri-Clamp DIN 32676	–	–	–	–	3 – 50	1/10" – 2"	16	T
					65 – 100	2½" – 4"	10	T
Fixed-Clamp	–	–	–	–	10 – 40	3/8" – 1½"	10	C
Ext. threads ISO 228 / DIN 2999	–	–	–	–	3 – 25	1/10" – 1"	10	E
Liner	PFA				PFA			
Conductivity	≥ 5 µS/cm				≥ 5 µS/cm			
Electrodes	Stn. stl. 1.4571[316Ti], 1.4539, Hastelloy C4, Platinum-Iridium, Tantalum, Titanium				Stn. stl. 1.4571[316Ti], 1.4539, Hastelloy C4, Platinum-Iridium, Tantalum, Titanium			
Process connection material	Stn. stl. 1.4404[316L], Optional 1.4435				Stn. stl. 1.4404[316L], Optional 1.4435			
Protection Class	IP 67, optional tropicalized				IP 67, optional tropicalized			

2 Accuracy, Reference Conditions and Operating Principle

2.1 Description

The Electromagnetic Flowmeters from ABB are the ideal flowmeters for liquids, slurries and sludges that have a specific minimum conductivity. The instruments measure accurately, create no additional pressure drop, have no moving parts or parts that project into the flow stream and are wear free. They can readily be installed in any existing pipeline.

ABB flowmeters have been proven over decades and are the preferred flowmeters in the chemical, pharmaceutical and cosmetic industries, in municipal water and waste water treatment facilities, the food industry and in pulp and paper plants.

2.2 Operating Principle

The operation of the electromagnetic flowmeter is based on Faraday's Laws of Induction. A voltage is induced in a conductor as it moves through a magnetic field.

This measurement principle is applied to a conductive fluid which flows in a pipe through which a magnetic field is generated perpendicular to the flow direction (see Schematic, Fig. 1).

$$U_E \sim B \cdot D \cdot v$$

The signal voltage which is induced in the fluid is measured at two electrodes located diametrically opposite to each other. This signal voltage U_E is proportional to the magnetic induction B , the electrode spacing D and the average fluid velocity v . From the equation for the volume flowrate *) it follows that: $U_E \sim q_v$. The signal voltage U_E is linear and proportional to the volume flowrate.




Fig. 1: Electromagnetic Flowmeter Schematic

2.3 Design

A very special position is occupied by the Compact Design electromagnetic flowmeters. In this design the converter is mounted directly on the flowmeter primary. This appreciably reduces the installation costs because no longer is wiring between the converter and the flowmeter primary required.

2.4 Reference Conditions per EN 29104

Fluid

Water, conductivity 200 $\mu\text{S}/\text{cm} \pm 10 \%$

Fluid Temperature

20 °C ± 2 K

Ambient Temperature

20 °C ± 2 K

Supply Power

Nominal voltage per the Type plate $U_N \pm 1\%$

Installation Requirements, Straight Pipe Sections

Upstream $>10xD$
 Downstream $>5xD$
 D = Size of the flowmeter primary

Warm-up Phase

≥ 30 Minutes

Influence on the Analog Output

Same as pulse output $\pm 0.1\%$ of rate

Pulse Output




Fig. 2: Accuracy

Reproducibility – Batch Operation

If the boundary conditions are constant, the above accuracy specifications / system accuracies ($\pm 0.5\%$ of rate) in

Fig. 2, for batch operation (standard deviation) become:

- $\pm 0.2\%$ at $T_{Batch} \geq 4$ s
- $\pm 0.4\%$ at $2 \text{ s} \leq T_{Batch} \leq 4$ s

Reproducibility – Continuous Operation

- $\pm 0.2\%$ of rate
- $\pm 0.4\%$ of rate

3 Assembly and Installation

3.1 Inspection

Before installing the electromagnetic flowmeter system, check for mechanical damage due to possible mishandling during shipment. All claims for damage are to be made promptly to the shipper before installing the flowmeter.

3.2 Transport General

3.2.1 Shipment Contents

Dependent on the converter variant included with the shipment of a FXF2000 are either 1 signal plug or 2 plugs for the compact design (Fig. 3). An Operation Manual and a Calibration Certificate are also included with the shipment for each instrument.

3.2.2 Shipped Status

The calibration data for the flowmeter primary is stored in the EEPROM which is plugged into the converter module. The parameters are set to their default values (Section 10) and the customer specified parameters listed in the ABB Specifications, if they were included with the order.




Fig. 3: Shipment Contents FXF2000 (COPA-XF)

3.3 Installation Requirements, Flowmeter Primary

When installing the flowmeter assure that the flow direction is correct (fluid flows into the plug connection), because the preferred flowmeter primary operation is the forward mode. It is possible to change the flow direction indicated in the display between forward/reverse in the software if required.

3.3.1 Installation

During installation assure that

- the flow direction agrees with the flow arrow - if present - on the flowmeter primary.
- the instrument is installed without mechanical stresses (torsion, bending), and that appropriate gaskets are used.
- the gaskets do not extend into the flow area as this might cause eddies which could adversely affect the accuracy of the instrument.
- the pipeline does not exert any unallowable forces or moments on the instrument.
- the plug when the installation is vertical points downward.
- the signal cable plug is properly installed and tightened, in order to assure Protection Class IP67 operation.
- the cover gasket is properly seated and the cover is screwed down tightly to assure IP67 operation.

- the instrument is grounded in accordance with the Interconnection Diagrams (see Section 4).

3.3.2 Recommended Installation Conditions

- Meter pipe must always be completely filled, because air can cause measurement errors.
- For horizontal installations, assure that neither electrode is located at the highest point, to exclude errors due to air bubbles. An ideal installation of an EMF is assured in a vertical pipeline. Fig. 4 shows the two preferred installation orientations.
- Valves or shutoff devices should be installed in the outlet section to prevent the meter from draining.




Fig. 4: Installation and Electrode Axis in the EMF

3.3.3 In- and Outlet Sections

The measurement principle is independent of flow profile as long as standing eddies do not extend into the measurement region (e.g. after double elbows, tangential inflows or half open valves upstream of the flowmeter primary). In such situations measures to condition the flow are required.

Straight pipe sections with the same internal opening as the flowmeter primary are to be installed up- and downstream. The straight length upstream of the flowmeter primary should be at least 10 times the size of the flowmeter primary and downstream at least 5 times. (Fig. 5)

Experience indicates that in most cases a straight upstream section with a length of 3 x D and a downstream section of 2 x D length are sufficient




Fig. 5: Pipeline Installations, Reductions if Required

3.3.4 Tightening Torques

**3.3.4.1 Tightening Torque M_A for Series 2000 „Multi-Connection“
Based on the PED(DGRL) Calculations using EPDM Gaskets**

Tightening Torques for Multi-Connection Instruments

DN	Inch	$M_A^{1)}$ [Nm]
DN 10	3/8"	6.5
DN 15	1/2"	9
DN 20	3/4"	20
DN 25	1"	32
DN 32	1 1/4"	56
DN 40	1 1/2"	80
DN 50	2"	30
DN 65	2 1/2"	42
DN 80	3"	100
DN 100	4"	125

1) Does not apply to Wafer Design flowmeters

**3.3.4.2 Tightening Torques M_A for Series 2000 with PFA Liners „Wafer Design“
Based on the PED(DGRL) Calculations**

Tightening Torques for Wafer Design Instruments

Liner	DN		Bolts	Torque max. Nm	PN bar
	mm	inch			
PFA	3 - 8 16	1/10 - 5/ 16	4 x M12	2.3	40
PFA	10	3/8	4 x M12	7.0	40
	15	1/2	4 x M12	7.0	40
	20	3/4	4 x M12	11.0	40
	25	1	4 x M12	15.0	40
	32	1¼	4 x M16	26.0	40
	40	1½	4 x M16	33.0	40
	50	2	4 x M16	46.0	40
	65	2½	8 x M16	30.0	40
	80	3	8 x M16	40.0	40
100	4	8 x M20	67.0	40	

3.3.5 3A Conformity

The instrument may not be installed in the orientation shown in Fig. 6. In addition, it is important that the leak detection hole be located at the lowest point in the installed instrument (Fig. 7).

The option „Mounting Bracket (Fig. 8)“ is not available for 3A-instruments.



Note:

The above noted requirements assure conformity to the 3A-Requirements relative to cleanability of NON fluid wetted parts on the exterior of the instrument. They have no effect on the operation, accuracy or operating reliability!




Fig. 6: Model DF23 – FXF2000 (COPA-XF)



Fig. 7:




Fig. 8:

3.4 Protection Class Relative to EMC

The Protection Class of the instrument is IP 67. The instrument is to be installed at a sufficient distance from EMC-noise sources such as frequency converters, valves, relays, heaters, etc., to eliminate effects on the accuracy and repeatability. If necessary, appropriate noise suppression measures should be provided such as protection diodes, varistors or R-C combinations (VDE 0580).

We recommend that shielded connection cables be used. It is advantageous to run the cables in grounded metal conduits, in which multiple cables of the same type can be run in the same conduit.



Note:

The instrument satisfies the requirements in the EMC-Directive and the NAMUR-Recommendations NE21 3/93 „Electromagnetic Compatibility of Equipment in Processes and the Laboratory“.

Grounding of the instrument and the connections for the signal cable are to be made as outlined in Section 4. „Grounding, Electrical Connections“.

3.5 Flowrate/Pressure Drop Tables and Nomograph

3.5.1 Meter Size and Pressure Rating (Weld Stubs) with Flow Ranges

Meter Size DN	Meter Size Inch	Std. Pres. Rating PN ¹⁾	Min. Flow Range Flow Velocity. 0 to 0.5 m/s	Max. Flow Range Flow Velocity. 0 to 10 m/s
3	1/10	40	0 to 0.2 l/min	0 to 4 l/min
4	5/32	40	0 to 0.4 l/min	0 to 8 l/min
6	1/4	40	0 to 1 l/min	0 to 20 l/min
8	5/16	40	0 to 1.5 l/min	0 to 30 l/min
10	3/8	40	0 to 2.25 l/min	0 to 45 l/min
15	1/2	40	0 to 5 l/min	0 to 100 l/min
20	3/4	40	0 to 7.5 l/min	0 to 150 l/min
25	1	40	0 to 10 l/min	0 to 200 l/min
32	1¼	40	0 to 20 l/min	0 to 400 l/min
40	1½	40	0 to 30 l/min	0 to 600 l/min
50	2	16	0 to 3 m ³ /h	0 to 60 m ³ /h
65	2½	10	0 to 6 m ³ /h	0 to 120 m ³ /h
80	3	16	0 to 9 m ³ /h	0 to 180 m ³ /h
100	4	10	0 to 12 m ³ /h	0 to 240 m ³ /h

1) For values for other process connections see Page 10

3.5.2 Effective Flow Velocities, Variable Process Connections, PFA

Meter Size DN	Meter Size Inch	Cal-fac [l/min]	d _{eff} [mm]	Q d _{eff} [l/min]	V _{eff} [m/s]
3	1/10	4	3	4.2	9.4
4	5/32	8	4	7.5	10.6
6	3/16	20	6	17.0	11.8
8	5/16	30	8	30.2	9.9
10	3/8	45	10	47.1	9.5
15	1/2	100	13	79.6	12.6
20	3/4	150	18	152.7	9.8
25	1	200	24	271.4	7.4
32	1¼	400	30	424.1	9.4
40	1½	600	36	610.7	9.8
50	2	1000	47	1041.0	9.6
65	2½	2000	62	1811.4	11.0
80	3	3000	74	2580.5	11.6
100	4	4000	96	4342.9	9.2

3.5.3 Flowrate Nomograph

The volume flowrate is a function of the flow velocity and flowmeter primary size. The Nomograph, Fig. 9, shows the flowrates which can be metered with a particular size flowmeter primary and which flowmeter sizes are suitable for a particular flowrate.

Example:

Flowrate = 120 l/min (maximum value = flow range end value).

Suitable are flowmeter sizes DN 20 to 65 [3/4" to 2½"].




Fig. 9: Flowrate Nomograph DN 3 to DN 100 [1/10" to 4"]

3.5.4 Pressure Drop Calculations

The flowmeter can readily be installed in larger size pipe lines by using of reducers. The pressure drop resulting from the reduction (e.g. flanged reducers per DIN EN 545) can be determined from the Nomograph Fig. 10 using the following procedure:

1. Calculate the diameter ratio d/D .
2. Calculate the flow velocity as a function of the meter size and the flowrate:
The flow velocity can also be determined from the Flow Rate Nomograph:

$$v = \frac{Q \text{ (Instantaneous flowrate)}}{\text{FlowmeterConstant}}$$

The flow velocity can also be determined from the Flow Rate Nomograph Fig. 9.

3. The pressure drop can be read on the -Y- axis at the intersection of the flow velocity curve and the "Diameter Ratio d/D " value on -X- axis in Fig. 10.




Fig. 10: Nomograph for Pressure Drop Determination

4 Grounding, Electrical Connections

4.1 General

The electrical connections may only be made by authorized technicians in accordance with the Interconnection Diagrams. Please observe the Interconnection Diagrams and the Notes in the Operation Manual. The connections described herein must be observed. When the housing is opened the EMC-Protection is voided.

4.2 Grounding the Flowmeter Primary

Grounding the flowmeter primary is essential for safety reasons as well as to assure proper functioning of the electromagnetic flowmeter. In accordance with VDE 0100, Part 540 a green/yellow Cu-cable (min. 4 mm²) is to be connected between the grounding screw on the flowmeter primary to protection earth (Fig. 11). For technical reasons this potential should be identical to the pipeline potential.




Fig. 11: Grounding the Flowmeter Primary FXF2000 (COPA-XF)

4.3 Interconnection Diagram for the FXF2000, P-Switched, Design Level B, Plug Assignments

Connection Plug (Supply Power, In-/Output)

Plug assignments
(Solder side)

- 1 white
- 2 green
- 3 gray
- 4 yellow
- 5 pink
- 6 red
- 7 blue
- 8 brown

Connection Plug - Angled

Option:
Plug with installed cable, PVC data cable, 5 m Type Tronic flexible per DIN 47100, LIYY 8 x 0.5 mm² Outside diameter 7.8 mm, Article No. 18091 Helukabel

Connection plug assignments with installed cable

Scaled pulse output passive, Opto, (P-switched)	Ux	Pin 3 (gray lead)
	V8	Pin 4 (yellow lead)
Current output 0/4 - 20 mA	+	Pin 5 (pink lead)
	-	Pin 8 (brown lead)
Contact output passive, Opto, (P-switched)	Ux	Pin 3 (gray lead)
	P7	Pin 1 (white lead)
Contact input passive, Opto, (P-switched)	X1	Pin 5 (pink lead)
	G2	Pin 2 (green lead)
Supply Power 24 V DC	U+	Pin 6 (red lead)
	U-	Pin 7 (blue lead)
No function Function		Pin 8 (brown lead)

Communication Plug

Pin connections

- 1 white
- 2 brown
- 3 green
- 4 yellow

Communication Plug (B) - Angled

Option:
Handheld terminal 55HT4000 with 2.5 m cable and straight plug or a 10 m cable with an angled plug (see Part No. 55HT4000)

Data link RS 485, 2 wire	A	Pin 4 (yellow lead)
	B	Pin 3 (green lead)
Supply power 24 V DC for Handheld terminal 55HT4000 from CM	⊥	Pin 1 (white lead)
	+25 V	Pin 2 (brown lead)

Fig. 12: Interconnection Diagram and Plug Assignments for Installed Cable

Plug PIN-Assignments

Plug Type Variant	Assignments for Standard Plug FXF2000								Assignments Communication Plug			
	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6	PIN 7	PIN 8	PIN 1	PIN 2	PIN 3	PIN 4
2	P7	G2	Ux	V8	X1	U+	U-	../..	⊥	+ 25 V	B	A
7	P7	X1	Ux	V8	+	U+	U-	-	../..	../..	../..	../..
User Specified Variants												
20	P7	../..	Ux	V8	+	U+	U-	-	⊥	+ 25 V	B	A
21	P7	G2	Ux	V8	X1	U+	U-	../..	../..	../..	../..	../..
22	P7	Vc	Ux	V8	+	U+	U-	-	../..	../..	../..	../..
23	P7	G2	Ux	V8	X1	U+	U-	Air	../..	../..	../..	../..

Interconnection Diagram FXF2000, P-Switched, Model DF23, Design Level B

Design P-Switched

(Pulse output, current output, contact input, contact output, supply power, external air, data link, supply power handheld terminal)

Assignment Plug PIN-No.	Connection Plug								Communication Plug			
	1	2	3	4	5	6	7	8	1	2	3	4
Legend	Functions (PIN-Assignments)								Functions (PIN-Assignments)			
a)			Ux	V8								
d)					+			-				
e)	P7		Ux									
f)		G2			X1							
g)						U+	U-					
i)											B	A
j)									⊥	+25V	B	A

a) Scaled pulse output, passive optocoupler, pulse width settable from 0.100 ms to 2000 ms
 $f_{max} \leq 5 \text{ kHz}$ dependent on selections in submenu "Operating Mode",
 $0 \text{ V} \leq U_{CEL} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$
 $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$; $0.2 \text{ mA} \leq I_{CEH} \leq 2 \text{ mA}$
 Connection assignments PIN 3, 4; Function Ux, V8

d) Current output (selectable)
 $\text{Load} \leq 600 \Omega$ for 0/4–20 mA, 0–10–20 mA, 4–12–20 mA
 $\text{Load} \leq 1200 \Omega$ for 0/2–10 mA; $\text{Load} \leq 2400 \Omega$ for 0–5 mA
 Connection assignments PIN 5 and 8; Function +, -

e) Contact output, function selectable, dependent on selections in submenu "Operating Mode",
 Synchronous-Signal (output signal synchronized to excitation), F/R-signal or end contact,
 passive optocoupler, $0 \text{ V} \leq U_{CEL} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$ / $0 \text{ mA} \leq I_{CEH} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$
 Connection assignments PIN 1, 3; Function P7, Ux

f) Contact input, function selectable dependent on selections in submenu "Operating Mode",
 Start/Stop, external totalizer reset, system zero¹⁾, No function,
 passive optocoupler, $16 \text{ V} \leq U \leq 30 \text{ V}$, $R_i = 2 \text{ k}\Omega$
 Connection assignments PIN 2, 5; Function G2, X1

g) Supply power 24 V DC $\pm 30 \%$ ripple $\leq 5 \%$
 Connection assignments PIN 6, 7; Function U+, U-

i) Data link RS 485, 2-wire, VPP = 5 V, input resistance $\geq 12 \text{ k}\Omega$
 max. cable length $\leq 1200 \text{ m}$, shielded, twisted pair cable required,
 Baudrate 110 - 9600 Baud, max. 32 instruments in parallel,
 Communication plug assignments PIN 3, 4; Function B, A (RS 485)

j) Connect handheld terminal 55HT4000
 Communication plug assignments PIN 3, 4; Function B, A (RS 485);
 Communication plug assignments PIN 1, 2; Function ⊥, +25 V (Supply power from CM for 55HT4000)

1) Initiates a system adjust procedure.
 The fluid must be at absolute zero, the meter pipe must be completely filled.

Comments:
 To maintain the EMC-Requirements the instrument must be connected to earth.
 When the housing is opened the EMC protection is voided.

Fig. 13: Interconnection Diagram, P-Switched In-/Outputs with PIN-Assignments for Connection and Communication Plugs

4.4 Interconnection Examples for Peripherals
 FXF2000 (COPA-XF), Model DF23, P-Switched In-/Outputs / Data Link




Fig. 14: Interconnection Examples for Peripherals, P-Switched In-/Outputs/Data Link

Variant Overview, P-Switched and SPC-Conformity




Fig. 15: Variant Overview P-Switched and SPC-Conformity

4.5 Communication

4.5.1 TTL-Service-Data Link for Communication with Operator Unit 55BE1000 or the Configuration Software

The instrument parameters can be changed, viewed or compared during start-up or if service is required using the Operator Unit 55BE1000 or a configuration software over the TTL-Service data link. It is a pure Service-Data link, to which, during normal operation, no other peripheral instruments may be connected.

Ordering Information Operator Unit 55BE1000

Ordering Number	55BE1	
Design		
With 9 V Battery for illuminating the display	10A	
Type Plate		
German		1
English		2



Attention!

When the converter housing is open, the EMC protection is reduced.




Fig. 16: Operator Unit 55BE1000 for Data Entry

4.5.2 RS485 Data Link for Communication with the Handheld Terminal 55HT4000 or a Higher Level Communication Unit

A PCS, SPC, PC or a Handheld Terminal 55HT4000 can be connected to the RS485 user data link. The connection to the RS485 is made using the separate 4 pole communication plug. For communication between the FXF2000 (COPA-XF) and a peripheral instrument the ASCII 2w protocol should be selected in the submenu „Data Link“.

Ordering Information Handheld Terminal 55HT4000

Ordering Number	55HT4				
Keypad layout					
Standard		1			
Supply Power					
24 V AC/DC			1		
Connection Cable with Plug					
2.5 m with straight plug, Handheld Terminal				1	
10 m with angled plug, for panel mounting				2	
Design Level					0
Type plate					
German					1
English					2



Fig. 17: Handheld Terminal 55HT4000 for Data Entry.
Prerequisite is a FXF2000 design which includes a Data link RS485 and the communication socket

5 Start-Up and Maintenance of the Flowmeter

Only after confirming that the previously described measures including

- Safety Information
- Assembly and Installation
- Grounding and Electrical Connections

have been completed in accordance with the instructions in this Operation Manual, can the EMF system be started-up. Before turning on the supply power check that the power supply values correspond to the values listed on the type plate. Also ascertain the following requirements have been satisfied:

- the specifications in Sections 6 and 7 have not been exceeded.
- the correct EEPROM is plugged into the converter.

Only then can the supply power be turned on.

After the supply power is turned on, the flowmeter primary data stored in the external EEPROM is compared to that stored internally in the converter. If the data are not identical, then an automatic upload is initiated. The desired parameters can now be set or selected.

- Select the desired mode of operation in the submenu „Operating Mode“.
- Enter your flow range in the submenu „Qmax“.
- Dependent on the selected Operating Mode:
 - configure the Pulse or Current Output.
 - configure the parameters such as Low Flow Cutoff, Damping, Unit, Display, In- and Outputs and the Data Link.
 - If the „Detector Empty Pipe“ is turned on, then the detector must be adjusted with the fluid to be metered at the operating conditions as described in this Operation Manual.

5.1 Sockets for the Memory Module (external EEPROM) and the Operator Unit

The sockets for the ext. EEPROM and the Operator Unit (55BE1000) are located on the front plate of the converter (Fig. 18).




Fig. 18:

5.2 Exchanging Components

When exchanging instrument components note the following information:



Attention!
When the converter housing is opened the EMC-Protection and the personnel contact protection are no longer provided.

5.2.1 Exchanging a Flowmeter Primary

- Turn off the supply power.

When exchanging a flowmeter primary (including the converter housing) be sure to remove the external EEPROM from the associated converter and keep it with the flowmeter primary. The EEPROM for the new flowmeter primary will be plugged into the converter. After the supply power is turned on the data in the converter will be automatically updated.

5.2.2 Exchanging a Converter

- Turn off the supply power.

The parameter settings are stored in an EEPROM, which is plugged into the converter module. When the module is exchanged, the EEPROM associated with the flowmeter primary is to be removed from the old converter and plugged into the new replacement converter. In addition to the data for the flowmeter primary, the parameter settings are also stored in this EEPROM. After the converter module has been exchanged and the EEPROM plugged in, the flowmeter primary data and the converter specific data are automatically updated into the converter.

5.3 System Zero Check

The System Zero for the flowmeter is set in the converter. The fluid flow must be brought to an absolute standstill and the meter pipe in the flowmeter primary must be completely filled. Then the parameter „System Zero“ can be called to manually or automatically adjust the zero value: Select the parameter with ENTER and use the arrow keys to select manual or automatic and accept with ENTER. During an automatic adjustment the converter counts down from 255 to the actual zero value. The progress is displayed in the 2nd line. When the adjustment is completed, the zero adjustment procedure is terminated. The adjustment takes approx. 20 seconds.

A zero adjustment should be made after the instrument start-up has been completed or after an instrument component has been exchanged. (See also Section 11.2 Parameter Overview).



Note!

If the FXF2000 is used as a flowmeter in a batch or filler application in the Operating Mode „Filler 5 kHz“, an automatic system zero adjustment can be initiated using the contact input during between the stop interval between batches .

5.4 Detector Empty Pipe

If the converter function „Detector Empty Pipe“ is turned on, it must be adjusted for the operating conditions with the fluid to be metered before start-up. The procedure is described in Section 11.2.

5.5 Storing the Parameter Settings

After the configuration has been completed, all the parameter settings should be stored in the external EEPROM. Call the menu function „Store Data in external EEPROM“, to save the settings which were changed or set during start-up.

5.6 Data Storage

Utilizing a NV-RAM. All data is stored when the supply power is turned off or a power outage occurs. All the parameter settings, process information and flowmeter primary specific calibration data is stored in the serial EEPROM and also in the external EEPROM. This procedure allows all the data to be uploaded into a replacement converter after exchanging the external EEPROM.

5.7 Maintenance/Repair

The flowmeter primary is essentially maintenance free. A yearly inspection should be conducted to check the ambient conditions (air flow, seal of the process connections, cable entries and cover screws, safety of the supply power, lightning protection and the ground connections. All repair and maintenance tasks should only be performed by qualified customer personnel. Observe the Note (Returns in the Section Hazardous Material Directives 1.1.14, Page 9), if the flowmeter primary is to be returned to the ABB Automation Products factory in Göttingen, Germany for repair.



Service Information!

When exchanging or repairing individual components only original replacement parts are to be used. Before beginning these tasks, make certain the supply power to the instrument has been turned off.

Connection Plugs and Fuses in the F4 Converter

! Note
Before removing the fuse, turn off the supply power

Fuse	Amps	Part No.
F101	1	D151B025U07
F103	0.125	D151F003U14

Fig. 19: Converter Module F4 (MAG-XF)

6 Specifications Flowmeter Primary DF23

6.1 Min. Allowable Absolute Pressure as a Function of the Fluid Temperature

Liner	Meter Size	$P_{Operate}$ mbar abs	at	$T_{Operate}$ °C
PFA	DN3-100 1/10"-4"	0	≤	130

6.2 Maximum Allowable Fluid Temperature and Pressure

Process Connections Liner PFA	Meter Size		$P_{Operate}$ bar	at	$T_{Operate}$ °C
	DN	Inch			
Wafer Design Weld stubs DIN 11850 Weld stubs DIN 2463	3-100	1/10-4	10 - 40	≤	130
Weld stubs ISO 2037	25-100	1-4	10 - 40	≤	130
Weld stubs SMS	25-100	1-4	10 - 40	≤	130
Food Ind. fitting DN 11851	3 - 40 50 - 100	1/10-1½ 2-4	40 10 - 16	≤	130
Tri-Clamp DIN 32676	3-100	1/10-4	10 - 16	≤	130
Fixed-Clamp	10-40	3/8-1½	10	≤	130
Ext. threads ISO 228 / DIN 2999	3-25	1/10-1	10	≤	130

6.3 Maximum Allowable Cleaning Temperature PFA-Design

CIP-Cleaning	Liner	T_{max} °C	T_{max} Minutes	T_{Amb} °C
Steam cleaning or Liquid cleaning	PFA	150 140	60 60	25 25

If the ambient temperature >25 °C, then the difference is to be subtracted from the max. cleaning temp.
 $T_{max} - \Delta T, \Delta T = (T_{Amb.} - 25 \text{ °C})$.

6.4 Maximum Allowable Shock Temperature

Liner	Temp.-Shock max. Temp.-Diff. °C	Temp.-Gradient °C/min
PFA	any	any

6.5 Ambient Conditions

Ambient temperature

$T_{Amb.} = -20 \text{ °C to } +60 \text{ °C}$

Fluid temperature

$T_{Fluid} = -25 \text{ °C to } +130 \text{ °C}$, CIP-cleanable, see Temperature Diagram and max. allowable cleaning temperatures.

Maximum allowable ambient temperature as a function of the fluid temperature for stainless steel process connections and Wafer Designs. (Fig. 20).




Fig. 20: Temperature Diagram

Storage temperature

$T_{Storage} = -25 \text{ °C to } +70 \text{ °C}$

6.6 Classifications per Pressure Equipment Directive (PED/DGRL)

The conformity evaluation for the FXF2000 (COPA-XF) instrument line is made according to PED/DRGL as Category III, Module B1+D, Fluid Group 1 or as „SEP“ (Art. 3, Par. 3).

6.7 Variant Overview Series 2000 (Stainless Steel Design) Model DF23

Meter Size DN Inch		Process Connection									PED/DGRL
		E	T	R	Q	P	X	S	F	W	
		Ext. threads	Tri-Clamp DIN 32676	Weld stubs DIN 11850	Weld stubs DIN 2463	Weld stubs ISO 2037	Weld stubs SMS	Food Ind. fitting DIN 11851	Flanged	Wafer Design	
3	1/10	x	x	x	x			x	x	x	SEP Art.3, Par. 3
4	5/32	x	x	x	x			x	x	x	
6	1/4	x	x	x	x			x	x	x	
8	5/16	x	x	x	x			x	x	x	
10	3/8	x	x	x	x			x	x	x	
15	1/2	x	x	x	x			x	x	x	
20	3/4	x	x	x	x			x	x	x	
25	1	x	x	x	x	x	x	x	x	x	Conformity evaluation per Category III Module B1+D, Fluid Group 1
32	1¼		x	x	x	x	x	x	x	x	
40	1½		x	x	x	x	x	x	x	x	
50	2		x	x	x	x	x	x	x	x	
65	2½		x	x	x	x	x	x	x	x	
80	3		x	x	x	x	x	x	x	x	
100	4		x	x	x	x	x	x	x	x	

6.8 Material Load Curve for Wafer Design Instruments Model DF23

Liner: PFA Wafer Design




Fig. 21: Material Load Curve for Wafer Design Instruments Model DF23 – Pressure/Temperature Diagram

6.9 Materials Flowmeter Primary

Liner Material	Electrode Material		Electrode Design	
	Standard	Others	Standard	Others
PFA	Hast.-C4 (1.4539 for Weld stubs, Food Ind. ftg. & Tri-Clamp)	SS No. 1.4539 SS No. 1.4571[316Ti] Tantalum, Titanium	Flat head	Pointed head (≥DN10[3/8"])

6.10 Process Connection Material

	Standard	Option
Wafer Design	None	
Weld stubs	SS No. 1.4404[316L]	SS No. 1.4435
Food Ind. fitting DIN 11851	SS No. 1.4404[316L]	SS No. 1.4435
Tri-Clamp DIN 32676	SS No. 1.4404[316L]	SS No. 1.4435
Fixed-Clamp	SS No. 1.4404[316L]	SS No. 1.4435
Ext. threads	SS No. 1.4404[316L]	SS No. 1.4435

6.11 Gasket Material, Electrical Connections, Weight and Design

Process Connection Material	Gasket Material
Wafer Design	None
Weld stubs Food Ind. fitting Tri-Clamp Fixed-Clamp Ext. threads	EPDM (Ethylene-Propylene) Std. with FDA-Approval Silicone with FDA-Approval (Option)
Flat housing gasket	Silicone

Supply Power

From converter

Weight

See Dimension Drawings Section 6.13

Design

Flowmeter primary with integrated µP-converter

Flowmeter primary and converter housing made of SS No. 1.4301 [304]

Process Connections DN 3 – 100 [1/10" – 4"]

See Page 10 and Section 6.13

Protection Class

Standard IP67, Option „tropicalized“

Max. Pipeline Vibration

10-58 Hz at 0.15 mm amplitude

58-150 Hz at 1.5 g acceleration

Max. allow. Fluid Temperature and Pressure Process Connections DF23

Process Connections	Meter Size		PS bar	at	TS °C
	DN	Inch			
Liner PFA Wafer Design	3-50	1/10-2	40	≤	130*)
	65-100	2½-4	16	≤	130*)
Weld stubs	3-40	1/10-1½	40	≤	130*)
	50, 80	2, 3	16	≤	130*)
	65, 100	2½, 4	10	≤	130*)
Tri-Clamp	3-50	1/10-2	16	≤	121
	65-100	2½-4	10	≤	121
Food Ind. fitting	3-40	1/10-1½	40	≤	130*)
	50, 80	2, 3	16	≤	130*)
	65, 100	2½, 4	10	≤	130*)
External threads	3-25	1/10-1	10	≤	130*)
Fixed-Clamp	10-40	3/8-1½	10	≤	130*)

*) Higher temperatures for CIP/SIP cleaning are allowed for limited time periods,
See Table „Max. allow. Cleaning Temperature“

6.12 Certifications /Approvals

The following have been granted for the FXF2000 (COPA-XF):
EHEDG-Certificate and 3A-Approval.

In addition, all the fluid wetted parts, such as liner and gaskets have the appropriate FDA-Approvals.

For the Series 2000 the Canadian CRN-Registration has also been granted.

6.13 Dimension Drawings DF23

6.13.1 Dimension Drawings, Flowmeter Primary DN 3-100 [1/10"-4"], Wafer Design, PFA




Fig. 22: Dimension Drawing, Model DF23, DN 3-100 [1/10" - 4"], Wafer Design

6.13.2 Dimension Drawings, flowmeter primary DN 3-100, variable Process Connections, PFA, Series 2000




Fig. 23: Dimension Drawing, Model DF23, DN 3-100, Variable Process Connections

6.13.3 Dimension Drawings, Adapters for Variable Process Connections, Series 2000




Fig. 24: Dimension Drawing, DN 3-100, Adapters for Variable Process Connections




Fig. 25: Dimension Drawing, DN 3-100 [1/10"-4"], Adapters for Variable Process Connections

7 Specifications Converter F4

7.1 Specifications Converter FXF2000 (COPA-XF)

Flow Range

Selectable between 0.05 – 1* Cal-fac

Reproducibility

0.2 % at $T_{Batch} \geq 4$ s
 0.4 % at $2 \text{ s} \leq T_{Batch} \leq 4$ s

Flow Direction

Forward / reverse

Minimum Conductivity

$\geq 5 \mu\text{S/cm}$, $\geq 20 \mu\text{S/cm}$ DN 3-8 [1/10"-5/16"], $\geq 20 \mu\text{S/cm}$ deionized water

Electrical Connections

8 pole plug (supply power and signals)
 4 pole plug (Data Link RS485 - option)

Supply Power

24 V DC , allowable voltage deviations +/-30 %
 Ripple ≤ 5 %

Power

DN 3 to DN 100 [1/10" to 4"] ≤ 6 W (flowmeter primary incl. converter)

Magnetic Field Excitation

12.5 Hz / 25 Hz

Ambient Temperature

-20 °C to +60 °C (See also Temperature Diagram Fig. 20)

Max. Pipeline Vibration

See Section 6.11

Response Time for Pulse/Frequency Output

Min. response time $T_{0/99} = \frac{1}{\text{Magneticfieldexcitation}}$

Min. batch time $T_{Abfull} = 2$ s

Zero Return

Set between 0 and 10 % of max.

Output Signals

- Scaled pulse output, passive, optocoupler
 $0 \leq U_{CEL} \leq 2$ V; $16 \text{ V} \leq U_{CEH} \leq 30$ V
 $2 \text{ mA} \leq I_{CEL} \leq 220$ mA; $0.2 \text{ mA} \leq I_{CEH} \leq 2$ mA
 Setting range: 0.001 – 1000 pulses per selected unit
 Pulse Width: 100 μ s – 2000 ms
 fmax: 5 kHz
 PIN 3 and 4
- Flowrate proportional frequency output
 1.2 or 5 kHz at flowrate = 100 %
 passive, optocoupler
 $0 \leq U_{CEL} \leq 2$ V; $16 \text{ V} \leq U_{CEH} \leq 30$ V
 $2 \text{ mA} \leq I_{CEL} \leq 220$ mA; $0.2 \text{ mA} \leq I_{CEH} \leq 2$ mA
 PIN 3 and 4
- Current output (selectable)
 Load $\leq 600 \Omega$ at 0/4–20 mA, 0–10– 20 mA, 4–12–20 mA
 Load $\leq 1200 \Omega$ at 0/2–10 mA

- Load $\leq 2400 \Omega$ at 0–5 mA
PIN 5 and 8
- Data Link RS 485
max. cable length 1200 m
max. number of instruments: 32 Instruments in parallel
max. Baudrate: 9600 Baud
Communication Protocol: ASCII 2W
“Communication plug” PIN 3 and 4
Connection for Handheld Terminal or SPC, PCS, PC
 - Handheld Terminal 55HT4000
Can be plugged into “Communication socket”
Supply Power 24 V DC on PIN 1 and 2
 - Contact output (function depends on Operating Mode setting)
Alarm- forward/reverse-, synchronous- or end contact, passive, optocoupler
 $0 \leq U_{CEL} \leq 2 \text{ V}$; $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$
 $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$, $0 \text{ mA} \leq I_{CEH} \leq 0.2 \text{ mA}$
PIN 1 and 3
 - Contact input (function depends on Operating Mode setting) Ext. zero return, system zero, synchronous input, Start/Stop input, optocoupler
 $16 \text{ V} \leq U \leq 30 \text{ V}$, $R_i = 2 \text{ k}\Omega$
PIN 5 and 2

7.2 Overview, Possible Converter Variants with Their Hardware Options and Operating Modes

Design Level B	Variant	
	02	07
Hardware		
Contact output	x	x
Contact input	x	x
Pulse passive	x	x
Current output		x
RS 485	x	
Menus		
Operating Mode		
Standard conti. K	x	x
Standard Batch B	o	o
Batch 1 kHz B1	o	o
Batch 2 kHz B2	o	o
Batch 5 kHz B5	o	o
Filler 5 kHz A	o	o
Conti 1 kHz K1	o	o
Conti 2 kHz K2	o	o
Conti 5 kHz K5	o	o
Contact output		
Alarm	x	x
Forward/Reverse	o	o
Synchronous	o	o
End contact	A	A
Contact input		
Ext. Zero Return	x	x
System zero	o	o
Start	A	A
Current output		K K1 K2 K5
Data Link		
ASCII	x	
ASCII2w	o	
DEP	K	K

Explanation:

x Default setting

o Selectable

A, B, K etc.: Selectable only with corresponding Operating Mode selections.

7.3 Functional Schematic of the FXF2000 (COPA-XF) as „Flow Sensor“ or „Stand-Alone Filler“




Fig. 26: Schematic of a Filler System with FXF2000 as Flow Sensor with Higher Level Filler Control




Fig. 27: Schematic and Electrical Connections for FXF2000 as Stand-Alone „Filler“ with Integrated Batch Software

Compact Design FXF2000 (COPA-XF)	DF23																			
Protection Class																				
IP 67 (Standard)																				
Tropicalized																				
Supply Power																				
24 V DC																				
External Connections																				
Connection plug (angled), (Standard),(for Variant selection 07)																				
Connection plug (angled), plus communication connector and plug (for Variant selection 02)																				
In-/Output (Variants) ³⁾		(See External Connections)																		
Contact output /pulse passive, opto /contact input/RS 485 (2nd plug)																				
Contact output /pulse passive, opto /contact input/current output (standard)																				
Application																				
Standard																				
Type Plate																				
German																				
English																				
Design Level																				
Gasket Material																				
EPDM with FDA-Approval (Standard)																				
Silicone with FDA-Approval (Option)																				
None (only Wafer Design)																				
Electrode Design																				
Standard																				
Pointed head ⁴⁾ (from DN 10 [3/8"])																				

3) Variant Nos. ≥ 20: customer specific Variants
 4) Use for high grease content fluids



Attention!

The Operator Unit 55BE1000 is required to configure the converters, whereby the housing cover must be removed.

Attention! When the housing cover is open, the EMC-Protection is restricted.

If a data link is installed in the converter, it can be configured without opening the housing cover by using the Handheld Terminal 55HT4000 or PCS-System or PC using the ASCII-Protocol.

9 Error Messages and Testing

9.1 Error Messages During Operation

.1.	A/D saturated
.2.	Uref too small
.3.	(set) Flowrate >130 %
.5.	RAM defect
.6.	Totalizer
.7.	Urefp too large
.8.	Urefn too large
.9.	Excitation
.B.	(set) Pulse calculation
.C.	

Error Register
3B

In the example the errors identified above (set) Error 3 (Flowrate >130 %) and Error B (Pulse calculation) have been detected. The display, after calling the parameter „Error Register“, appears as shown to the left in the Operator Unit.

The following list contains explanations for the error codes outputted by the converter.

Error Code	Detected System Error	Corrective Measures
1	A/D-Converter	Reduce flowrate, throttle valve.
2	Positive or negative reference too small	Check min-fuse F103, See Page 27.
3	Flowrate greater than 130 %	Reduce flowrate, increase flow range.
5	RAM defect Function 1: Data in EEPROM corrupted Function 2: Stored data in NVRAM	Start test program, possibly reinitialize. Request customer number from ABB Service Dept.; No corrective measures. Information: Corrupted data in RAM, the converter initiates an automatic reset and uploads the data from the EEPROM.
7	Positive reference too large	Magnetic field excitation incorrect.
8	Negative reference too large	Contact ABB-Service.
6	Totalizer error	Difference totalizer incorrect.
9	Excitation frequency in correct	Reset difference totalizer forward/reverse, See Section 11.2 „Parameter Overview“
C	Flowmeter primary data invalid	Supply power error on the digital signal board. The flowmeter primary data in the external EEPROM are invalid. In submenu „Flowmeter Primary“ compare values with those on the type plate. If the values agree, the error message can be reset using „Store Primary“. If the values are not identical, the flowmeter primary data must first be reentered and when finished, call „Store Primary“. Contact ABB-Service.
B	Incorrect calculation or pulse factor	Contact ABB-Service.

9.2 Error Messages During Data Entry

The following list contains explanations for the error codes outputted by the converter.

Error Code	Detected System Error	Corrective Measures
10	Entry >1.00 Cal-fac >10 m/s	Reduce flow range Qmax
11	Entry < 0.005 Cal-fac < 0.5 m/s	Increase flow range Qmax
16	Entry >10 % Low Flow Cutoff	Reduce entry value
17	Entry < 0 % Low Flow Cutoff	Increase entry value
38	Entry >1000 pulses/unit	Reduce entry value
39	Entry < 0/.001 pulses/unit	Increase entry value
40	Max. totalizer frequency exceeded, scaled pulse output, pulse factor (5 kHz)	Reduce pulse factor
41	Value below min. totalizer frequency < 0.00016 Hz	Increase pulse factor
42	Entry >2000 ms pulse width	Reduce entry value
43	Entry < 0.1 ms pulse width	Increase entry value
46	Entry too large	Reduce pulse width entry value
54	Flowmeter primary zero >50 Hz	Check ground and ground signals. A zero adjustment can be made if the flowmeter primary is filled with fluid and the flowrate is at absolute zero.
91	Data in EEPROM corrupted	Data in internal EEPROM invalid, See Error Code 5 for corrective measures.
92	Data in ext. EEPROM corrupted	Data (e.g. Qmax, Damping) in external EEPROM invalid, access possible. The error message can be cleared by calling the function „Store data in ext. EEPROM“.
93	Ext. EEPROM corrupted or not installed	No access possible, component defective. If the component is not installed, then install the actual ext. EEPROM associated with the flowmeter primary
94	Incorrect version ext. EEPROM	The database has not been updated to the present software version. Use the function „Load Data from ext. EEPROM“ to automatically upload the external data. The function „Store Data in ext. EEPROM“ clears the error message.
95	External flowmeter primary data corrupted	See Error Code C.
96	Incorrect version EEPROM	Database in EEPROM has a different version than the installed software. Use the function „Update“ to reset the error.
97	Flowmeter primary incorrect	The flowmeter primary data in the internal EEPROM are invalid. Use the function „Load Primary“ to clear the error. (See Error Code C).
98	EEPROM corrupted or not installed	No access possible, component defective. If the component is not installed, then plug in the actual ext. EEPROM associated with the flowmeter primary.
99	Entry too large	Reduce entry
99	Entry too small	Increase entry

10 Parameter Setting Overview with Default Values

10.1 Specification Help: FXF2000, 50XF4000, Design-Level B, Variant 02

Order Number:		Name:		
Customer:		Date:		
Parameter	Selection/Entry	Default	Range	Comments
Variant	<input type="checkbox"/> 02			
Meter Size	<input type="checkbox"/> DN 3 <input type="checkbox"/> 1/10" <input type="checkbox"/> DN 4 <input type="checkbox"/> 5/32" <input type="checkbox"/> DN 6 <input type="checkbox"/> 1/4" <input type="checkbox"/> DN 8 <input type="checkbox"/> 5/16" <input type="checkbox"/> DN 10 <input type="checkbox"/> 3/8" <input type="checkbox"/> DN 15 <input type="checkbox"/> 1/2" <input type="checkbox"/> DN 20 <input type="checkbox"/> 3/4" <input type="checkbox"/> DN 25 <input type="checkbox"/> 1" <input type="checkbox"/> DN 32 <input type="checkbox"/> 1¼" <input type="checkbox"/> DN 40 <input type="checkbox"/> 1½" <input type="checkbox"/> DN 50 <input type="checkbox"/> 2" <input type="checkbox"/> DN 65 <input type="checkbox"/> 2½" <input type="checkbox"/> DN 80 <input type="checkbox"/> 3" <input type="checkbox"/> DN 100 <input type="checkbox"/> 4"			Excitation freq. for DN 3- 40[1/10"-1½"]: 25 Hz Excitation freq. for DN 50-100[2"-4"]: 12 1/2 Hz
Flow Range Qmax		1*Cal-fact	0.05 to 1*Cal-fact	
Unit Qmax	<input type="checkbox"/> ml/s <input type="checkbox"/> l/s <input type="checkbox"/> ml/min <input type="checkbox"/> l/min <input type="checkbox"/> Others:	l/min From DN 50[2"]: m3/h		
Unit Totalizer	<input type="checkbox"/> ml <input type="checkbox"/> l <input type="checkbox"/> Others:	l From DN 50[2"]: m3		
Density		1 g/cm3	0.1 to 5 g/cm3	Only for mass units
Operating Mode	<input type="checkbox"/> Standard conti. <input type="checkbox"/> Conti. 1 kHz <input type="checkbox"/> Conti. 2 kHz <input type="checkbox"/> Conti. 5 kHz <input type="checkbox"/> Standard Batch <input type="checkbox"/> Batch 1 kHz <input type="checkbox"/> Batch 2 kHz <input type="checkbox"/> Batch 5 kHz <input type="checkbox"/> Filler 5 kHz	Standard conti.		
Pulse Factor		1/Unit	0.001 to 1000	Only for OM „Standard...“
Pulse Width		30 ms	0.1 to 1000 ms	Only for OM „Standard...“
Damping		5 s	0.125 to 20 s	Only for „conti.“ OM
Low Flow Cutoff		1 %	0 to 10 %	
Flow indication	<input type="checkbox"/> normal <input type="checkbox"/> inverse	normal		
Flow Direction	<input type="checkbox"/> F/R <input type="checkbox"/> forward	Forward/reverse		
Prog. Output P7	<input type="checkbox"/> No function <input type="checkbox"/> General Alarm norm. closed <input type="checkbox"/> General Alarm norm. open <input type="checkbox"/> F/R-Signal <input type="checkbox"/> Synchronous Signal	General Alarm norm. closed		For OM „Filler“ always „End Contact“
Protocol	<input type="checkbox"/> ASCII <input type="checkbox"/> ASCII2w	ASCII		If more than one in- strument, ASCII2w must be selected
Baudrate	<input type="checkbox"/> 1200 Bd <input type="checkbox"/> 2400 Bd <input type="checkbox"/> 4800 Bd <input type="checkbox"/> 9600 Bd	1200 Bd		
Address		0	0 to 99	
Language	<input type="checkbox"/> German <input type="checkbox"/> English	German		

10.2 Specification Help: FXF2000, 50XF4000, Design-Level B, Variant 07

Order Number:		Name:		
Customer:		Date:		
Parameter	Selection/Entry	Default	Range	Comments
Variant	<input type="checkbox"/> 07			
Meter Size	<input type="checkbox"/> DN 3 <input type="checkbox"/> 1/10" <input type="checkbox"/> DN 4 <input type="checkbox"/> 5/32" <input type="checkbox"/> DN 6 <input type="checkbox"/> 1/4" <input type="checkbox"/> DN 8 <input type="checkbox"/> 5/16" <input type="checkbox"/> DN 10 <input type="checkbox"/> 3/8" <input type="checkbox"/> DN 15 <input type="checkbox"/> 1/2" <input type="checkbox"/> DN 20 <input type="checkbox"/> 3/4" <input type="checkbox"/> DN 25 <input type="checkbox"/> 1" <input type="checkbox"/> DN 32 <input type="checkbox"/> 1 1/4" <input type="checkbox"/> DN 40 <input type="checkbox"/> 1 1/2" <input type="checkbox"/> DN 50 <input type="checkbox"/> 2" <input type="checkbox"/> DN 65 <input type="checkbox"/> 2 1/2" <input type="checkbox"/> DN 80 <input type="checkbox"/> 3" <input type="checkbox"/> DN 100 <input type="checkbox"/> 4"			Excitation freq. for DN 3- 40[1/10"-1 1/2"]: 25 Hz Excitation freq. for DN 50-100[2"-4"]: 12 1/2 Hz
Flow Range Qmax		1*Cal-fact	0.05 to 1*Cal-fact	
Unit Qmax	<input type="checkbox"/> ml/s <input type="checkbox"/> l/s <input type="checkbox"/> ml/min <input type="checkbox"/> l/min <input type="checkbox"/> Others:	l/min From DN 50[2"]: m3/h		
Unit Totalizer	<input type="checkbox"/> ml <input type="checkbox"/> l <input type="checkbox"/> Others:	l From DN 50[2"]: m3		
Density		1 g/cm3	0.1 to 5 g/cm3	Only for mass units
Operating Mode	<input type="checkbox"/> Standard conti. <input type="checkbox"/> Conti. 1 kHz <input type="checkbox"/> Conti. 2 kHz <input type="checkbox"/> Conti. 5 kHz <input type="checkbox"/> Standard Batch <input type="checkbox"/> Batch 1 kHz <input type="checkbox"/> Batch 2 kHz <input type="checkbox"/> Batch 5 kHz <input type="checkbox"/> Filler 5 kHz	Standard conti.		
Pulse Factor		1/Unit	0.001 to 1000	Only for OM „Standard...“
Pulse Width		30 ms	0.1 to 1000 ms	Only for OM „Standard...“
Damping		5 s	0.125 to 20 s	Only for „conti.“ OM
Low Flow Cutoff		1 %	0 to 10 %	
Flow indication	<input type="checkbox"/> normal <input type="checkbox"/> inverse	Normal		
Flow Direction	<input type="checkbox"/> F/R <input type="checkbox"/> forward	Forward/reverse		
Prog. Input X1	<input type="checkbox"/> No function <input type="checkbox"/> Ext. Zero Return	Ext. Zero Return		For OM „Filler“ always „Start-Input“
Prog. Output P7	<input type="checkbox"/> No function <input type="checkbox"/> General Alarm norm. closed <input type="checkbox"/> General Alarm norm. open <input type="checkbox"/> F/R-Signal <input type="checkbox"/> Synchronous Signal	General Alarm norm. closed		For OM „Filler“ always „End Contact“
Current Output	<input type="checkbox"/> 0-20 mA <input type="checkbox"/> 4-20 mA <input type="checkbox"/> Others:	0-20 mA		Only for „conti.“ Operating Mode
lout at Alarm	<input type="checkbox"/> 0 % <input type="checkbox"/> 130 % <input type="checkbox"/> 3.6 mA	0 %		Only for „conti.“ Operating Mode
Language	<input type="checkbox"/> German <input type="checkbox"/> English	German		

11 Data Entry and Programming Using Operator Unit 55BE1000

11.1 Data Entry and Programming Using Operator Unit 55BE1000

Data is entered using 3 keys. After the Program Protection has been turned off the parameters can be selected using the ENTER-Function, the STEP-/or DATA key can be used to either select the setting for the parameter from the list in the table, or to enter a numerical value. During data entry the converter remains online, i.e. the instrument continues to operate normally. The functions of the keys are described below.




Fig. 28: Operator Unit 55BE1000

- C/CE Use the C/CE-Key to toggle between normal operation and the menus.
- STEP ↓ The STEP-Key is one of two arrow keys. Use STEP to scroll forward through the menu. All desired parameters can be accessed.
- DATA ↑ The DATA-Key is one of two arrow keys. Use DATA to scroll backward through the menu. All desired parameters can be accessed.
- ENTER The ENTER-Function is activated by pressing both arrow keys, STEP and DATA, simultaneously. First use ENTER to turn the program protection off. Then use ENTER to access the parameter to be changed and then to confirm the new entries or selections. Finally use ENTER to turn the program protection on again.

The ENTER-Function is active for approx. 10 seconds. If no action occurs within this 10 second interval, the converter the old value is displayed again.

There are two types of entry modes:

- Numeric entry
- Selection from a list in a table.



Information!

During data entry the values entered are checked for plausibility and if invalid they are rejected and an appropriate message is displayed.














Caution!

When the converter housing is open the EMC-Protection and the personnel contact protection are voided.

11.2 Parameter Overview

Legend: ENTER = DATA + STEP

Submenu/Parameters	Comments
	<p>Process display</p>
	<p>Data can only be entered when the Program Protection is turned off.</p>
	<p><u>Tabular Selection</u> on/off</p>
	<p><u>Numeric Entry</u> If a number other than „0“ (factory default setting) has been entered for the Prog. Prot.-Code, then the Prog. Prot. can only be turned off after this number has been entered as the PP-Code (1-255) .</p>
	<p><u>Display</u> When the Prog. Prot. is turned off, parameters cannot be changed.</p>
	<p>When the Program Protection is turned off, the PP-Code can be changed.</p>
	<p><u>Numeric Entry</u> Enter old PP-Code 0 = Factory default setting</p>
	<p><u>Numeric Entry</u> Enter new PP-Code (0-255).</p>
	<p><u>Tabular Selection</u> German or English can be selected as the language for the display</p>
	<p><u>Display</u> Flowmeter primary specific data</p>
	<p><u>Display</u> Present meter size See type plate on flowmeter primary.</p>

Submenu/Parameters	Comments
	<p><u>Display</u> Max. flowrate for the meter size at 10 m/s flow velocity</p>
	<p><u>Display</u> Span value Cs for the flowmeter primary at the selected excitation frequency. See type plate.</p>
	<p><u>Display</u> Zero value Cz for the flowmeter primary at the selected excitation frequency. See type plate.</p>
	<p><u>Display</u> Short Model No. of the flowmeter primary</p>
	<p><u>Display</u> Order No. for the flowmeter. This number is identical to the number listed on the type plates on the flowmeter primary and the converter and on the tag on the external EEPROM.</p>
	<p><u>Numeric Entry</u> Entry of the max. flowrate at which the current output corresponds to 20 mA.</p>
	<p style="text-align: right;">CM-Variant 21</p> <p><u>Display</u> Display of the pulse factor (dependent on Operating Mode)</p>
	<p style="text-align: right;">CM-Variants 02/05/07</p> <p><u>Numeric Entry</u> Entry or display the pulse factor (dependent on Operating Mode) The pulse factor is calculated by the converter so that the output frequency set in the submenu „Operating Mode“ is achieved at 100 % Flowrate (= Qmax). In the operating modes with a scaled pulse output („Standard Conti“ and „Standard Batch“) a pulse factor from 0.001 to 1000 pulses/unit can be programmed by the user, (fmax = 5 kHz).</p>

Submenu/Parameters	Comments
	<p><u>Numeric Entry</u> For the external pulse output. Range 0.1 ms-2000 ms in multiples of 0.064 ms. The max. allow. pulse width is checked by the software and corrected if necessary.</p>
	<p><u>Numeric Entry</u> Range 0-10 % of the set flow range end value (Qmax). Applies to the displayed values and all outputs. The switching point for the low flow cutoff incorporates a hysteresis of 0.5 %. In the Operating Mode „Filler 5 kHz“ this function only applies to the display indications.</p>
	<p style="text-align: right;">CM-Variants 02/05/07</p> <p><u>Numeric Entry</u> The damping parameters are only displayed in the Operating Modes „conti“. In the other operating modes there is no damping.</p>
	<p><u>Numeric Entry</u> Range 0.01-5 g/cm³. Mass flowrate for the display and totalizer values in g, kg, t, uton or pounds.</p>
	<p>System Zero in Hz based on Cal-fac (Cal-fac is equivalent to 10000 Hz)</p> <p><u>Numeric Entry</u> Manual entry, e.g. when a converter is exchanged</p> <p><u>Automatic Adjustment</u> Valve must be closed, flowrate must be at absolute zero and the meter pipe must be completely filled. The automatic adjustment is started with ENTER. The limits for the zero value are ± 50 Hz. If the value is outside of these limits, no adjustment is made.</p>
	<p>Selection of the units for Qmax, totalizer and the user programmable units and units factor</p> <p><u>Tabular Selection</u> ml/s, ml/min, ml/h, Ml/min, Ml/day, lb/s, lb/min, lb/h, uton/min, uton/h, uton/day, kgal/s¹⁾, kgal/min¹⁾, kgal/h¹⁾, l/s, l/min, l/h, hl/s, hl/min, hl/h, m³/s, m³/min, m³/h, igps, igpm, igph, mgd, gpm, gph, bbl/s, bbl/min, bbl/h, bls/day, bls/min, bls/h, kg/s, kg/min, kg/h, t/s, t/min, t/h, g/s, g/min, g/h.</p> <p>The units are used for Cal-fac, Qmax forward, Qmax reverse and the instantaneous display values, when direct reading engineering units have been selected.</p> <p>¹⁾ User programmable units</p>

Submenu/Parameters	Comments
<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Unit Totalizer </div> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 10px; margin-left: 10px;">ENTER</div> </div> <div style="text-align: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px 15px;">STEP</div> </div>	<p><u>Tabular Selection</u> l, hl, m³, igan, gal, mgal, bbl, bls, kg, t, g, ml, MI, lb, uton, kgal¹⁾ 1) User programmable units</p> <p>The selected direct reading engineering units for the totalizer are checked by the computer based on the values for the flow range, pulse factor, pulse width (0.1 ms to 2000 ms) and the density correction factor if mass units have been selected (e.g. g, kg, t). When the value of one these parameters is changed, the pulse width may not exceed 50% of the period of the output frequency at 100 % flowrate (on/off ratio 1:1). If the pulse width is larger, it is automatically reduced to 50 % of the period and a message "Warning: New Pulse Width" is displayed. If the output frequency is outside of the limits a message is also displayed. The invalid entry is rejected .</p>
<p>Footnote 1)</p> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Unit Factor 3785.41 Liter</div> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 10px; margin-left: 10px;">ENTER</div> </div> <div style="text-align: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px 15px;">STEP</div> </div>	<p><u>Numeric Entry</u> User programmable flowrate units, based on liters; value shown is the factor for kgal units (factory default setting).</p>
<p>Footnote 1)</p> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Unit Name kgal /s /min /h</div> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 10px; margin-left: 10px;">ENTER</div> </div> <div style="text-align: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px 15px;">STEP</div> </div>	<p><u>Numeric Entry</u> Four character name for the programmable units.</p>
<p>Footnote 1)</p> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Prog. Unit No Density</div> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 10px; margin-left: 10px;">ENTER</div> </div>	<p><u>Tabular Selection</u> Programmable units for mass (with density) or volume flowrate (without density)</p>
<div style="border: 1px solid black; padding: 5px; display: inline-block; width: 150px;">Submenu Alarm</div> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 10px; margin-left: 10px;">ENTER</div> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin-left: 10px;">Error Register 0 . . . 3 . . .</div>	<p><u>Display</u> All detected errors (Error 0-C) are stored.</p>
<div style="text-align: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px 15px;">STEP</div> </div> <div style="text-align: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Reset: ENTER</div> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin-left: 10px;">Help text: STEP</div> </div> <div style="text-align: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px 15px;">STEP</div> </div>	<p><u>Display</u> Use ENTER to clear the Error Register.</p>
<div style="text-align: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">. 3 . set</div> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin-left: 10px;">Flowrate >130 %</div> </div> <div style="text-align: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">. 8 .</div> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin-left: 10px;">Urefn too large</div> </div>	<p><u>Display</u> After pressing the STEP-Key a clear text explanation is displayed for each error code. Active errors are identified by "(set)".</p> <p>Use the C/CE-Key to exit the help menu. For additional information relating to the topic error messages and checks, see Section 9.</p>

Footnote 1): Only for user programmable units









Submenu/Parameters	Comments
<pre> graph TD S1[Submenu Prog. In/Output] -- ENTER --> T1[Terminal P7 Synchron. Signal] T1 -- STEP --> T2[Terminal X1 No Function] T2 -- ENTER --> S1 </pre>	<p>The function assigned to the contact in- or output is dependent on the selections made for the operating mode (in submenu „Operating Mode“).</p> <p style="text-align: right;">CM-Variant 21</p> <p><u>Display</u></p>
<p style="text-align: center;">or</p> <pre> graph TD S2[Submenu Prog. In/Output] -- ENTER --> T3[Terminal P7/Ux Synchron-Signal] T3 -- STEP --> T4[Terminal P7/Ux FR-Signal] T4 -- STEP --> T5[Terminal P7/Ux End Contact] T5 -- STEP --> T6[Terminal P7/Ux General Alarm] T6 -- STEP --> T7[Terminal P7/Ux No Function] T7 -- STEP --> T8[Terminal X1/G2 Start/Stop] T8 -- STEP --> T9[Terminal X1/G2 System Zero] T9 -- STEP --> T10[Terminal X1/G2 Ext. Zero Return] </pre>	<p>The function assigned to the contact in- or output is dependent on the selections made for the operating mode (in submenu „Operating Mode“)</p> <p style="text-align: right;">CM-Variants 02/05/07</p> <p><u>Tabular Selection</u></p> <p>The output signal is synchronized to the magnetic field excitation from the converter. Improved reproducibility for short batch cycles can be achieved by synchronizing the opening of the magnet valve to the magnetic field excitation from the converter.</p> <p>Output signal for the forward flow direction (contact closed for forward).</p> <p>In the Operating Mode „Batch“, the end contact is opened when the batch quantity is reached.</p> <p>Output signal when errors are detected as a general alarm indicator</p> <p>Contact output not used</p> <p>If the Operating Mode „Filler 5 kHz“ is selected, the contact input operates as an ext. Start/Stop contact.</p> <p>The function „System Zero“ initiates an automatic adjustment of the system zero.</p> <p>The output signals are set to zero by the ext. Zero Return function.</p>

Submenu/Parameters	Comments
<p>Terminal X1/G2 No Function</p>	<p>Contact input not used.</p>
<p>2) Submenu Data Link</p>	<p>CM-Variant 02 The option „Data Link“ is dependent on the CM-Variant.</p>
<p>ENTER Communication ASCII 2w ENTER STEP</p>	<p><u>Tabular Selection</u> Selection of the Communication-Protocol - ASCII 2w - ASCII</p>
<p>Instrument Addr. 0 ENTER STEP</p>	<p><u>Numeric Entry</u> Entry of the Instrument Address. The address of the 1st instrument must always be „0“.</p>
<p>Baudrate 1200 Bd ENTER</p>	<p><u>Tabular Selection</u> Selection of the Baudrate - 1200 Bd - 2400 Bd - 4800 Bd - 9600 Bd</p>
<p>3) Submenu Current Output</p>	<p>CM-Variants 05/07 The option „Current Output“ is dependent on the CM-Variant.</p>
<p>ENTER Current Output 0-20 mA ENTER STEP</p>	<p><u>Tabular Selection</u> Selection of the current output range - 0-20 mA - 4-20 mA - 0-10 mA - 2-10 mA - 0-5 mA - 0-10-20 mA - 4-12-20 mA</p>
<p>lout at Alarm 0 % ENTER</p>	<p><u>Tabular Selection</u> Selection of the value for the current output during an error. - 0 % - 130 % - 3.6 mA</p>
<p>Submenu Function Test</p>	<p>This test set can be used to test the functions in the converter, the in-/and outputs and the wiring before start-up.</p>
<p>ENTER Function Test lout ENTER STEP</p>	<p>Only for converters with current output hardware.</p>

Footnote 2): Only with Data Link RS485 hardware

Footnote 3): Only for Operating Modes Standard Conti, Conti 1/2/5 kHz.

Submenu/Parameters	Comments
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test RAM (ASIC) -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Display</u> RAM (ASIC) ----- Error Free</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test NVRAM -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Display</u> NVRAM ----- Error Free</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test EPROM (Program) -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Display</u> EPROM ----- Error Free</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test EEPROM -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Display</u> EEPROM ----- Error Free</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test ext. EEPROM -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Display</u> ext. EEPROM ----- Error Free</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test Terminal P7 -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Tabular Selection</u> Terminal P7 - off - on</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test RS485 -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p>Only for converters with Data Link RS485 hardware</p>
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">STEP</div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;">Function Test Pulse Output -----</div> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; width: 30px; margin: 0 auto;">ENTER</div> </div> </div>	<p><u>Display</u> Pulse Output ----- (1 Hz)</p>

Submenu/Parameters	Comments
	<p><u>Display</u> 1234567890 ABCDEF 1234567890 ABCDEF</p>
	<p><u>Tabular Selection</u> Terminal X1 - off - on Only for converters with Input X1 hardware.</p>
	<p><u>Display</u> Simulation on</p> <p><u>Display</u> Simulation off</p>
	<p><u>Display</u> Test Mode on</p> <p><u>Display</u> Test Mode off</p>
<p>4)</p> 	<p>CM-Variants 02/05/07 The option „Detector e. Pipe“ is dependent on the CM-Variant.</p>
	<p><u>Tabular Selection</u> - off - on (Turn this function on)</p>
	<p><u>Tabular Selection</u> - on - off (Turn this function off)</p>
	<p><u>Tabular Selection</u> - off - on (Turn on the alarm)</p>

Footnote 4): Only for Operating Mode „Standard Conti“



Submenu/Parameters	Comments
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> lout at e.Pipe 0 % </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="STEP"/> </div>	<p><u>Tabular Selection</u></p> <ul style="list-style-type: none"> - 0 % - 130 % - 3.6 mA <p>(set the value of the current during an error condition)</p>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Threshold 2300.0 Hz </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="STEP"/> </div>	<p><u>Numeric Entry</u></p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;"> Threshold Q Hz </div> <p>Enter the threshold value for the detector. The standard setting is 2300 Hz. Dependent on fluid and application (conductivity) the value may be set higher or lower. ($F_{max} = 3000$ Hz)</p>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Adjust Detector e. Pipe </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div>	<p><u>Tabular Setting</u></p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;"> Adjust 19000. Hz 200 </div> <p style="text-align: right; margin-right: 20px;">← Digital Potentiometer</p> <p>Assure that the pipeline is completely filled with fluid and that the flowrate = 0. Use STEP/DATA to set the standard adjustment value of 2000 Hz (± 25 Hz), and store using „ENTER“. Empty the instrument and check if the frequency displayed exceeds the standard value of 2300 Hz. ! For fluids with large conductivity changes, it may be necessary to set a different threshold value. Check to make certain that the difference between the threshold value and the adjustment frequency is at least 300 Hz ($\rightarrow F$ Threshold ≥ 300 Hz $\rightarrow F$ full pipe). ! When metering multiple products with widely differing conductivities (particularly lower conductivities) it is important that the „Detector e. Pipe“ be adjusted at the lowest conductivity.</p>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Totalizer </div>	<p>Presetting and resetting the totalizer values Presetting the totalizer (totalizer value settable) 2nd display line = present value Enter a negative value to preset the reverse flow totalizer. If the totalizer overflows in the forward direction, the overflow counter "Overflow $\rightarrow F$" is incremented by one if no overflows have been registered in the reverse direction. If reverse overflows have been counted, then this counter is first decremented by one. The action in the opposite direction is analogous. In the Operating Mode "Conti. 1 kHz" (2/5 kHz) or "Standard" this totalizer essentially operates as a difference totalizer, i.e. the counter adds in the forward direction and subtracts in the reverse direction.</p>
<div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> 5) Diff. Totalizer reset </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="STEP"/> </div>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;"> reset? yes \rightarrow ENTER </div> <p>Reset the difference totalizer.</p>
<div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> 5) Diff. Totalizer $\rightarrow F$ 80.0000 l </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="ENTER"/> </div> <div style="text-align: center; margin-bottom: 10px;"> <input type="button" value="STEP"/> </div>	<p><u>Numeric Entry</u></p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;"> Diff. Totalizer Q </div> <p>Preset the difference totalizer value. Use a negative entry to preset the reverse flow direction.</p>

Footnote 5): In „Standard“ and „Batch“ Operating Modes



Submenu/Parameters	Comments																
<div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 15%;">STEP</div> <div style="width: 80%;"> <p>5) Overflow →F 2 ENTER</p> <p style="text-align: center;">STEP</p> </div> </div>	<p><u>Display</u></p> <div style="border: 1px solid black; padding: 2px; width: 100%;">Overflow →F 0</div>																
<div style="display: flex; justify-content: space-between;"> <div style="width: 80%;"> <p>5) Overflow ←R 1 ENTER</p> </div> </div>	<p><u>Display</u></p> <div style="border: 1px solid black; padding: 2px; width: 100%;">Overflow ←R 0</div>																
or	<p>If the difference totalizer overflows in the forward direction, the overflow counter "Overflow →F" is incremented by one if there are no overflows in the reverse direction. If there were overflows counted in the reverse direction, then the counter is first decremented by one. The other flow direction behaves in an analogous manner. Calculation example for overflows:</p> <p>Overflow 012</p> <table style="margin-left: 20px; border-collapse: collapse;"> <tr> <td style="padding-right: 10px;">12 x</td> <td style="padding-right: 10px;">10,000,000</td> <td style="padding-right: 10px;">units</td> <td></td> </tr> <tr> <td>=</td> <td>120,000,000</td> <td>units</td> <td></td> </tr> <tr> <td>+</td> <td>23,455</td> <td>present totalizer value</td> <td style="border-top: 1px solid black;"></td> </tr> <tr> <td></td> <td>120,23,455</td> <td>units</td> <td></td> </tr> </table>	12 x	10,000,000	units		=	120,000,000	units		+	23,455	present totalizer value			120,23,455	units	
12 x	10,000,000	units															
=	120,000,000	units															
+	23,455	present totalizer value															
	120,23,455	units															
<div style="display: flex; justify-content: space-between;"> <div style="width: 80%;"> <p>6) Totalizer reset ENTER</p> <p style="text-align: center;">STEP</p> </div> </div>	<p><u>Automatic. Reset</u></p> <div style="border: 1px solid black; padding: 2px; width: 100%;">reset? yes → ENTER</div>																
<div style="display: flex; justify-content: space-between;"> <div style="width: 80%;"> <p>6) Totalizer set ENTER</p> <p style="text-align: center;">STEP</p> </div> </div>	<p><u>Numeric Entry</u></p> <div style="border: 1px solid black; padding: 2px; width: 100%;">Totalizer 0</div>																
<div style="display: flex; justify-content: space-between;"> <div style="width: 80%;"> <p>6) Overflow →F 2 ENTER</p> <p style="text-align: center;">STEP</p> </div> </div>	<p><u>Display</u></p> <div style="border: 1px solid black; padding: 2px; width: 100%;">Overflow →F 0</div>																
<div style="display: flex; justify-content: space-between;"> <div style="width: 80%;"> <p>6) Overflow ←R 1 ENTER</p> </div> </div>	<p><u>Display</u></p> <div style="border: 1px solid black; padding: 2px; width: 100%;">Overflow ←R 0</div>																
<div style="border: 1px solid black; padding: 5px; width: 15%; margin-top: 20px;"> Submenu Display </div>																	


Footnote 5): In „Standard“ - and „Batch“ Operating Modes
 Footnote 6): In Operating Mode „Filler 5 kHz“

Submenu/Parameters	Comments
	<p><u>Tabular Selection</u> (Assigning the values to display in 1st Line)</p> <p><u>1st Line</u></p> <ul style="list-style-type: none"> - Q [Unit]_ - Difference totalizer_ - TAG Number_ - Q [Bargraph]_ - Blank line_ - Q [%]_
	<p><u>Tabular Selection</u> (Assigning the values to display in 2nd Line)</p> <p><u>2nd Line</u></p> <ul style="list-style-type: none"> - Difference totalizer_ - TAG Number_ - Q [Bargraph]_ - Blank line_ - Q [%]_ - Q [Unit]_
	<p><u>Tabular Selection</u> Assigning the multiplexed value to display in 1st Line. Display cycles every 10 Sec.</p> <p><u>1st Line multipl.</u></p> <ul style="list-style-type: none"> - off_ - Q [%]_ - Q [Unit]_ - Difference totalizer_ - TAG Number_ - Q [Bargraph]_
	<p><u>Tabular Selection</u> Assigning the multiplexed value to display in 2nd Line. Display cycles every 10 Sec.).</p> <p><u>2nd Line multipl.</u></p> <ul style="list-style-type: none"> - off_ - Q [%]_ - Q [Unit]_ - Difference totalizer_ - TAG Number_ - Q [Bargraph]_
	<p>The Operating Mode is fixed for user specified CM-Variants!</p>
	<p style="text-align: right;">CM-Variant 21</p> <p><u>Display</u></p>
	<p><u>Tabular Selection</u></p> <ul style="list-style-type: none"> - Forward/Reverse - Forward <p>Select if the totalizer is to integrate flow in both forward and reverse directions or only in the forward direction.</p>

Submenu/Parameters	Comments
	<p><u>Tabular Selection</u></p> <ul style="list-style-type: none"> - inverse - normal <p>The setting depends on the installation orientation of the flowmeter primary. As standard, the instrument should be installed so that it normal operation is in the forward flow direction (flow direction into the connection plugs).</p>
<p>or</p> 	<p style="text-align: right;">CM-Variants 02/05/07</p> <p><u>Tabular Selection</u></p> <p>The Operating Mode settings are located in the Service Code Number section. During the „Batch Operating Modes“ the reference voltage measurements are usually made between two batch cycles. In the „Conti Operating Modes“ the reference voltage measurement is made at specific time intervals.</p> <ul style="list-style-type: none"> - Operating Mode „Standard Conti“ should be selected for continuous flow metering. The pulse factor can be user programmed. Fmax = 5 kHz. The output P7/G2 transmits a F/R-Signal (Forward/reverse direction signal). - Operating Mode „Standard-Batch“. For batch and filler processes with user programmable pulse output (Fmax = 5 kHz). - Operating Mode „Batch 1 kHz“. For batch and filler processes with a fixed 1 kHz frequency output at Qmax (Qmax = 100 % Flowrate = 1 kHz) <p>The pulse factor is calculated so that an output frequency of 1 kHz exists at 100 % Flowrate (= Qmax). For batch operation the synchronous output should be selected for the valve control.</p> <ul style="list-style-type: none"> - Operating Mode „Batch 2 kHz“. Similar to Operating Mode „Batch 1 kHz“, except max. output frequency = 2 kHz. - Operating Mode „Batch 5 kHz“. Similar to Operating Mode „Batch 1 kHz“, except max. output frequency = 5 kHz. - Operating Mode „Conti 1 kHz“. For continuous flowrate metering. The pulse factor is calculated so that an output frequency of 1 kHz exists at 100 % Flowrate (= Qmax). - Operating Mode „Conti 2 kHz“. Similar to Operating Mode „Conti 1 kHz“, except max. output frequency = 2 kHz. - Operating Mode „Conti 5 kHz“. Similar to Operating Mode „Conti 1 kHz“, except max. output frequency = 5 kHz. - Operating Mode „Filler 5 kHz“. ! Not available for „CM-Variant 05“ ! For Stand-Alone filler operation. For continuous flowrate metering. The pulse factor is calculated so that an output frequency of 5 kHz exists at 100 % flowrate. The output P7/G2 has the function of an End Contact, the input X1/G2 has the function of a Start Contact. During the fill cycle the input X1/G2 has the function of a Stop Contact.

Submenu/Parameters	Comments
	<p><u>Tabular Selection</u></p> <ul style="list-style-type: none"> - Forward/Reverse - Forward <p>Select if the flowrate should be integrated in both flow directions, forward and reverse or only in the forward direction. If the forward only option is selected and a reverse flow is present, the flow direction indicator „← R“ in the display blinks and the flowrate indication is 0 %.</p>
	<p><u>Tabular Selection</u></p> <ul style="list-style-type: none"> - normal - inverse <p>If the flow direction indicators differ from the actual flow direction because of the installation orientation of the flowmeter primary, this function (inverse) can be used to switch the flow direction indicators..</p>
	<p><u>Display</u></p>
	<p>When exchanging a converter the data stored in the external EEPROM is automatically uploaded. It is also possible to upload the data upon command from the external EEPROM.</p> <p><u>Automatic Upload</u> using ENTER. A prerequisite is that the meter location parameters had previously been stored (See the following parameter).</p>
	<p>After start-up has been completed, the new meter location parameters should be stored in the external EEPROM.</p>
	<p><u>Automatic Download</u> using ENTER.</p>
	<p style="text-align: right;">CM-Variant 21</p> <p><u>Display</u></p>
	<p style="text-align: right;">CM-Variants 02/05/07</p> <p><u>Display</u> Displays the Model Number of the instrument and identifies the installed software version and the EPROM Part Number</p> <p>08/96 Date of the release A.22 Revision level</p>
	<p><u>Numeric Entry</u> An alphanumeric TAG-Number with a max. of 16 characters can be entered to identify the meter location using numbers and upper and lower case letters</p>


Submenu/Parameters	Comments
	<p>Only for ABB Automation Products Service personnel.</p> <p><u>Numeric Entry</u> After a correct Service-Code No. is entered, the instrument specific parameters and calibration data can be accessed. Only for ABB Automation Products Service or ABB authorized personnel.</p>
<p>If the Operating Mode „Filler 5 kHz“ is selected then the following parameters will also be displayed. They are located between the submenu „Primary“ and the parameter „Qmax“.</p>	
	<p style="text-align: right;">CM-Variants 02/05/07</p> <p><u>Tabular Selection</u> There are 3 sets of parameters available for 3 different fill quantities: Batch 1, Batch 2, Batch 3. Each parameter set includes the fill quantity, calibration and maximum fill time.</p> <p>Select the parameter set for fill quantity 1.</p> <p>Select the parameter set for fill quantity 2.</p> <p>Select the parameter set for fill quantity 3.</p> <p><u>Display</u> As a function of the present operating status of the instrument the available function is displayed and can be activated with ENTER.</p> <p><u>Numeric Entry</u> Entry of the quantity to be filled. Only positive entries may be made. The units are those selected in parameter „Unit Totalizer“ in submenu „Unit“.</p>


Submenu/Parameters	Comments
<p>Calibration 1 1.2345 %</p> <p>ENTER</p> <p>Calibration 1 -</p> <p>ENTER</p> <p>STEP</p>	<p><u>Numeric Entry</u> A separate „Calibration“ can be programmed for each batch. The entry range is $\pm 10\%$.</p>
<p>Max. Fill Time 1 10.500 s</p> <p>ENTER</p> <p>Max. Fill Time 1 -</p> <p>ENTER</p> <p>STEP</p>	<p><u>Numeric Entry</u> A separate „Max. Fill Time“ can be programmed for each batch. After the time has expired the fill cycle is automatically terminated. The entry range is 0-2600 s.</p> <p>These last 3 parameters are also available for Fill Quantity 2 and 3.</p>
<p>Max. Fill Time 3 20.000 s</p> <p>ENTER</p> <p>Max. Fill Time 3 -</p> <p>ENTER</p> <p>STEP</p>	<p>Settings for parameter sets 2 and 3 See „Parameter set Fill Quantity 1“</p>
<p>Measure Qn to 2 Stage time tn</p> <p>ENTER</p> <p>Measure Qn to 2 Stage time tn</p> <p>ENTER</p> <p>STEP</p> <p>Measure Qn to Valve shut tv</p> <p>ENTER</p>	<p><u>Tabular Selection</u> The second stage flow can be determined using two different methods, up to: - second stage time tn - valve closed time tv</p>  <p>The graph shows flow rate Q on the y-axis and time t on the x-axis. The flow starts at 0, rises to a plateau, and then falls back to 0. The time from the start of the rise to the end of the plateau is labeled 'tn'. The time from the end of the plateau to the point where the flow rate reaches 0 is labeled 'tv'. The points where the flow rate starts to rise and ends to fall are labeled 'Valve opened' and 'Valve closed' respectively.</p>
<p>2 Stage time tn 0.5000 s</p> <p>ENTER</p> <p>2 Stage time tn -</p> <p>ENTER</p> <p>STEP</p>	<p><u>Numeric Entry</u> The second stage flow time tn defines how long the flowrate should continue to be metered after the End Contact opens. The range for the second stage flow time is 0 - 10 s. It must be greater than the valve closing time.</p>
<p>Valve shut tv 0.3300 s</p> <p>ENTER</p> <p>Valve shut tv -</p> <p>ENTER</p> <p>STEP</p>	<p><u>Automatic Measurement or Numeric Entry</u> Is determined by the computer itself. The valve closure time is defined as the time from the opening of the End Contact until the flowrate reaches < 1 %.</p>
<p>2 Stage Qty Qn 0.2345 l</p> <p>STEP</p>	<p><u>Display</u> The second stage quantity Qn is the quantity of flow which is measured from the time the End Contact is activated until the valve closes within the Second Stage Time or the Valve Closed Time.</p>

Submenu/Parameters	Comments
<p>The diagram shows a flowchart starting with a box containing '2 Stage Corr. Averaging'. A vertical line leads to a 'STEP' button. From the 'STEP' button, a horizontal line leads to an 'ENTER' button, which then leads to a box containing '2 Stage Corr. Averaging'. From this box, a vertical line leads to another 'STEP' button. From this second 'STEP' button, a horizontal line leads to an 'ENTER' button, which leads to a box containing '2nd Stage Corr. Manual'. From this box, a vertical line leads to an 'ENTER' button.</p>	<p><u>Tabular Selection</u> Selection of the type of calculation which is to be used for the second stage quantity correction</p>
<p>The second stage correction quantity is an average value calculated from the number of fill cycles entered in the parameter "Averaging Factor"</p>	
<p>Entry of a fixed second stage correction quantity</p>	
<p>The diagram shows a flowchart starting with a box containing 'Averaging factor 003'. A vertical line leads to a 'STEP' button. From the 'STEP' button, a horizontal line leads to an 'ENTER' button, which leads to a box containing 'Averaging factor -'. From this box, a vertical line leads to an 'ENTER' button.</p>	<p><u>Numeric Entry</u> The averaging factor defines the number of fill previous cycles which are to be used to calculate the second stage correction quantity. Range 2-5.</p>
<p>The diagram shows a flowchart starting with a box containing '2 Stage Corr. Qty. -0.2134 l'. A vertical line leads to a 'STEP' button. From the 'STEP' button, a horizontal line leads to an 'ENTER' button, which leads to a box containing '2 Stage Corr. Qty. -'. From this box, a vertical line leads to an 'ENTER' button.</p>	<p><u>Automatic Determination or Numeric Entry</u> The calculated second stage correction quantity determined either automatically (Averaging) or entered as a fixed correction quantity (Manual). Entries must be negative.</p>

12 Certificates

12.1 EC-Declaration of Conformity (DGRL 97/23/EG)




 0045

EG-Konformitätserklärung
EC-Declaration of Conformity

Hiermit bestätigen wir die Übereinstimmung des aufgeführten Gerätes mit den Richtlinien des Rates der Europäischen Gemeinschaft, welche mit dem CE-Zeichen gekennzeichnet sind. Die Sicherheits- und Installationshinweise der Produktdokumentation sind zu beachten.
Herewith we confirm that the listed instrument is in compliance with the council directives of the European Community and are marked with the CE marking. The safety and installation requirements of the product documentation must be observed.

<p>Hersteller: <i>manufacturer:</i></p> <p>Modell: <i>model:</i></p> <p>Richtlinie: <i>directive:</i></p> <p>Einstufung: <i>classification:</i></p> <p>Normengrundlage: <i>technical standard:</i></p> <p>Konformitätsbewertungsverfahren: <i>conformity assessment procedure:</i></p> <p>EG-Entwurfsprüfbescheinigung: <i>EC design-examination certificate:</i></p> <p>benannte Stelle: <i>notified body:</i></p> <p>Kennnummer: <i>identification no.</i></p>	<p>ABB Automation Products GmbH, 37070 Göttingen - Germany</p> <p>FXE4000, FXM2000, FSM4000, FXL4000, FXT4000, FXF2000 (D_2..., D_2_W, D_4_W, SE2..., SE2_W)</p> <p>Druckgeräterichtlinie 97/23/EG <i>pressure equipment directive 97/23/EC</i></p> <p>Ausrüstungsteile von Rohrleitungen <i>pipng accessories</i></p> <p>AD 2000 Merkblätter</p> <p>B1 (EG-Entwurfsprüfung) + D (Qualitätssicherung Produktion) <i>B1 (EC design-examination) + D (production quality assurance)</i></p> <p>Nr. 07 202 0124 Z 052/2/0006</p> <p>TÜV Nord e.V. Rudolf-Diesel-Str. 5 37075 Göttingen - Germany</p> <p>0045</p>
--	---

Göttingen, den 17.09.2004

ppa
 (J. Harr, Standortleiter APR Göttingen)

2310 BZ-25-0006 Rev 02

12.2 EC-Certificate of Compliance (EMC Directive)



**EG-Konformitätserklärung
EC-Certificate of Compliance**



Hiemit bestätigen wir die Übereinstimmung der aufgeführten Geräte mit den Richtlinien des Rates der Europäischen Gemeinschaft. Die Sicherheits- und Installationshinweise der Produktdokumentation sind zu beachten.

Herewith we confirm that the listed instruments are in compliance with the council directives of the European Community. The safety and installation requirements of the product documentation must be observed.

Modell: DF2300
Model:

Richtlinie: EMV Richtlinie 89/336/EWG
Directive: EMC directive 89/336/EEC

Europäische Norm: EN 50081-1, 3/93 EN 50081-2, 3/94
European Standard: EN 50082-1, 3/93 EN 50082-2, 2/96

* einschließlich Nachträge
including alterations

Göttingen, 12.05.2000

.....
Unterschrift Signature

BZ-13-5025, Rev.1, 1699

ABB Automation Products GmbH

Postanschrift: D-37070 Göttingen	Telefon: +49(0)551 905-0 Telefax: +49(0)561 905-777 http://www.abb.de/automation UST-IdNr.: DE 119 300 097	Sitz der Gesellschaft: Göttingen Registergericht: Göttingen Handelsregister: HRB 423	Vorsitz des Aufsichtsrates: Bengt Pihl Geschäftsführung: Uwe Alwardt (Vorsitz) Burkhard Block Erik Huggare	Commerzbank AG Frankfurt Konto: 589 635 200 BLZ: 500 400 00
-------------------------------------	--	---	---	---

ABB has Sales & Customer Support
expertise in over 100 countries worldwide.

www.abb.com

ABB optimiert kontinuierlich ihre Produkte,
deshalb sind Änderungen der technischen Daten
in diesem Dokument vorbehalten.

Printed in the Fed. Rep. of Germany (12.05)

© ABB 2005



ABB Ltd.

Oldends Lane, Stonehouse
Gloucestershire, GL 10 3TA
UK

Phone: +44(0)1453 826661
Fax: +44(0)1453 829671

ABB Inc.

125 E. County Line Road
Warminster, PA 18974
USA

Phone: +1 215 674 6000
Fax: +1 215 674 7183

ABB Automation Products GmbH

Dransfelder Str. 2
37079 Göttingen
GERMANY

Phone: +49 551 905-534
Fax: +49 551 905-555

CCC-support.deapr@de.abb.com