

Automatic Range Change Facility for SP80 Software


1 Overview

SP80 software introduces an automatic range change facility on the second current output, via a relay. The ranges are selected in the **Set Up Parameters Page** and are described in this publication.

Caution. The second current output configuration is preset in the **Factory Settings** page. DO NOT change the **Adjust RTX 2 Span** or **Adjust RTX 2 Zero** values.

2 Programming

2.1 Set Up Parameters Page – 8037



– press to advance to next parameter

or

– press to advance to **Set Up Outputs Page**.


Range

	Zero	Span
1	0.0 µg/kg	99.9 µg/kg
2	0 µg/kg	999 µg/kg
3	0.00 mg/kg	9.99 mg/kg

Units

Refer to IM/8037

2.2 Set Up Parameters Page – 9438



Press to advance to next parameter

or

Press to return to **Set Up Alarm Page**.

Range

	Zero	Span
1	0 µg/kg	200 µg/kg
2	0.00 mg/kg	2.00 mg/kg
3	0.0 mg/kg	20.0 mg/kg

Display Units

Refer to IM/9438

ABB has Sales & Customer Support expertise
in over 100 countries worldwide

www.abb.com

The Company's policy is one of continuous product
improvement and the right is reserved to modify the
information contained herein without notice.

Printed in UK (09.08)

© ABB 2008



ABB Limited
Oldends Lane, Stonehouse
Gloucestershire
GL10 3TA
UK
Tel: +44 (0)1453 826661
Fax: +44 (0)1453 829671

ABB Inc.
125 E. County Line Road
Warminster
PA 18974
USA
Tel:+1 215 674 6000
Fax:+1 215 674 7183