

SACE Tmax XT

RHL - Blocco a chiave per frontale/maniglia rotante XT1-XT2-XT3-XT4 in posizione di aperto


RHL - Key lock for XT1-XT2-XT3-XT4 front/rotary handle, open position

RHL - Schlüsselverriegelung für Frontplatte/Drehhebelantrieb XT1-XT2-XT3-XT4 in AUS-Stellung


RHL - Verrouillage par clé pour frontal/poignée rotative XT1-XT2-XT3-XT4 en position d'ouvert

RHL - Bloqueo con llave para frontal/mando giratorio XT1-XT2-XT3-XT4 en posición de abierto


XT1-XT2-XT3-XT4




RHD-RHE-FLD




A RHD




B RHD




C RHD




D RHE



E RHE




F RHE




G

FLD




H

FLD



I

FLD



For more information please contact:

ABB S.p.A.
 ABB SACE Division
 Via Baioni, 35
 24123 Bergamo - Italy
 Phone: +39 035 395 111
 Fax: +39 035 395 306 - 433
www.abb.com