




# SACE Tmax XT

AUX-C - Contatti ausiliari cablati 400V XT2-XT4/ F-P-W  
AUX-C - Wired auxiliary contacts, 400V XT2-XT4/ F-P-W  
AUX-C - Hilfskontakte verdrahtet, 400V XT2-XT4/ F-P-W  
AUX-C - Contacts auxiliaires câblés 400V XT2-XT4/ F-P-W  
AUX-C - Contactos auxiliares cableados 400V XT2-XT4/ F-P-W


XT2-XT4/III-IV




**A** F-P




**B** F-P




**C** SY/1+Q/2




**D** SY/1+Q/2



**E** Q/1+Q/2




**F** Q/1+Q/2




G

F-P




H

F-P




SY/1+Q/2

W




Q/1+Q/2

W




I

W




J

w





K

w





L

SY/1+Q/2




M

Q/1+Q/2




N

w




O

w




P

w




Q


w



R

w





For more information please contact:

ABB S.p.A.  
 ABB SACE Division  
 Via Baioni, 35  
 24123 Bergamo - Italy  
 Phone: +39 035 395 111  
 Fax: +39 035 395 306 - 433  
 www.abb.com